






Conventional
Hub Assemblies



PreSet®
Hub Assemblies



PreSet Plus®
Hub Assemblies



Hub & Rotor
Assemblies

SERVICE MANUAL

For Steer, Drive, and Trailer Hub Assemblies

ABOUT THIS MANUAL

Before You Begin

- Read this manual carefully, providing extra attention to its explanations and instructions.
- To ensure safe, continuous, trouble-free operation, understand your wheel hub system, and keep all components in proper operating condition.
- Pay particular attention to all NOTES, CAUTIONS, WARNINGS, and DANGERS to avoid the risk of personal injury or property damage, and realize these statements are not exhaustive. ConMet® cannot possibly know or evaluate all conceivable methods in which service may be performed or the possibly hazardous consequences of each method. Accordingly, those who use a procedure not recommended by ConMet must first satisfy themselves that neither their safety nor the safety of the product will be jeopardized by the service method selected.
- Use only ConMet approved replacement parts. Do not attempt to use damaged parts.
- Follow your company's maintenance and service, installation, and diagnostics guidelines.
- Use special tools when required to help avoid serious personal injury and damage to components.

Color Coding

Throughout this manual we will use the following colors to help identify specific areas that reference Conventional, PreSet®, and PreSet Plus® ConMet hubs.

Conventional	<div></div>
PreSet	<div></div>
PreSet Plus	<div></div>

If a color is not specified, then you can conclude the information is mutual for all hub assemblies.

Hazard Alert Messages

<div><div></div><div>DANGER</div></div> <p>A Danger alert indicates a hazardous situation which, if not avoided, <i>will result in death or serious injury.</i></p>
<div><div></div><div>WARNING</div></div> <p>A Warning alert indicates a hazardous situation which, if not avoided, <i>could result in death or serious injury.</i></p>
<div><div></div><div>CAUTION</div></div> <p>A Caution alert indicates a hazardous situation which, if not avoided, <i>could result in minor or moderate injury.</i></p>
<div><div></div><div>NOTE</div></div> <p>A Note includes additional information that may assist the technician in service procedures.</p>

Additional Maintenance and Service Information

On the Web

Visit conmet.com to access ConMet's product, sales, service and maintenance literature.

ConMet Customer Service

Call ConMet's Customer Service at 1-800-547-9473.

ConMet Decals

The following decals are available upon request:

Decal Name	PreSet Part Number	PreSet Plus Part Number
Disc Wheel Installation Procedures	103282	103282
Hubs Lubricated with Oil	106873	10038167
Hubs Lubricated with Semi-Fluid Grease	107383	10038168

TABLE OF CONTENTS

1. INTRODUCTION	1
Conventional Hubs	1
PreSet Hub Assemblies	1
PreSet Plus Hub Assemblies	1
2. INSPECTION	2
HAZARD ALERT MESSAGES	2
WHEEL END INSPECTION GENERAL GUIDELINES	2
Driver Pre-Trip Visual Inspection	2
In Route Inspections	2
Preventative Maintenance Schedule	2
Service Interval	3
Lubrication Analysis	3
3. IDENTIFICATION	4
WHEEL MOUNTING SYSTEMS	4
Hub Pilot Wheel Mounting	4
Ball Seat Wheel Mounting System	4
IDENTIFYING CONMET HUB ASSEMBLIES	4
Vehicle Identification Number (VIN)	4
Casting Number	4
Machining Number	4
Final Hub Assembly Number	5
Julian Date	5
Conventional Wheel Hubs	5
PreSet Wheel Hubs	5
PreSet Plus Wheel Hubs	5
4. CONVENTIONAL WHEEL HUBS	6
HUB REMOVAL AND DISASSEMBLY	6
COMPONENT INSPECTION AND REPLACEMENT HAZARD ALERT MESSAGES	7
CLEAN AND DRY COMPONENTS	7
Worn or Damaged Components	7
Hub and Component Cleaning	7
INSPECTING BEARING CUPS AND CONES	8
REMOVING CUPS IN ALUMINUM HUBS	8
REMOVING CUPS IN IRON HUBS	8
INSTALLING A NEW CUP IN ALUMINUM HUBS	8
INSTALLING A NEW CUP IN IRON HUBS	8
WHEEL STUDS	9
STUD REMOVAL	9
STUD REPLACEMENT	9
HUB, DRUM AND WHEEL INSPECTION	9
ABS TONE RING INSPECTION (AS APPLICABLE)	9
REMOVAL AND INSTALLATION OF MACHINED ABS TONE RING	10
REMOVAL AND INSTALLATION OF STAMPED STEEL ABS TONE RING	10
REMOVAL AND INSTALLATION OF BOLT ON ABS TONE RINGS	10
REASSEMBLY	11
CONVENTIONAL WHEEL HUBS ASSEMBLY	11
REINSTALLATION	12
INSTALLING ConMet CONVENTIONAL WHEEL HUBS	12
Spindle Preparation	12
Conventional Hub Installation	12
Manual Bearing Adjustment Procedure (reference TMC RP618)	13
SERVICE PARTS	14
5. PRESET WHEEL HUBS	17
HUB REMOVAL AND DISASSEMBLY	17
COMPONENT INSPECTION AND REPLACEMENT HAZARD ALERT MESSAGES	18
CLEAN AND DRY COMPONENTS	19
Worn or Damaged Components	19
Hub and Component Cleaning	19
INSPECTING BEARING CUPS AND CONES AND BEARING SPACER	19
REMOVING CUPS IN ALUMINUM HUBS	19
REMOVING CUPS IN IRON HUBS	20
INSTALLING A NEW CUP IN ALUMINUM HUBS	20
INSTALLING A NEW CUP IN IRON HUBS	20
WHEEL STUDS	20
STUD REMOVAL	20
STUD REPLACEMENT	20
HUB, DRUM AND WHEEL INSPECTION	21
ABS TONE RING INSPECTION (AS APPLICABLE)	21
REMOVAL AND INSTALLATION OF ABS TONE RING	21
REMOVAL AND INSTALLATION OF STAMPED STEEL ABS TONE RING	21
REMOVAL AND INSTALLATION OF BOLT ON ABS TONE RINGS (For Disc Brakes)	22
REASSEMBLY	23
PreSet WHEEL HUBS	23
REINSTALLATION	25
INSTALLING THE PreSet WHEEL HUB ASSEMBLY	25
Spindle Preparation	25
Mounting the Hub	25
Spindle Nut Torque	25
SERVICE PARTS	26

TABLE OF CONTENTS

6. PRESET PLUS WHEEL HUBS	29
HUB REMOVAL AND DISASSEMBLY	29
COMPONENT INSPECTION AND REPLACEMENT HAZARD ALERT MESSAGES	31
CLEAN AND DRY COMPONENTS	31
Worn or Damaged Components	31
Hub and Component Cleaning	31
INSPECTING BEARING CUPS AND CONES AND BEARING SPACER	31
REMOVING CUPS IN ALUMINUM HUBS	32
REMOVING CUPS IN IRON HUBS	32
INSTALLING A NEW CUP IN ALUMINUM HUBS	32
INSTALLING A NEW CUP IN IRON HUBS	32
WHEEL STUDS	32
STUD REMOVAL	33
STUD REPLACEMENT	33
HUB, DRUM AND WHEEL INSPECTION	33
ABS TONE RING INSPECTION (AS APPLICABLE)	33
REMOVAL AND INSTALLATION OF ABS TONE RING	33
REMOVAL AND INSTALLATION OF STAMPED STEEL ABS TONE RING	34
REMOVAL AND INSTALLATION OF BOLT ON ABS TONE RINGS (For Disc Brakes)	34
REASSEMBLY	35
PreSet Plus WHEEL HUBS	35
Spindle Nut and Spiral Snap Ring Reassembly	36
REINSTALLATION	37
INSTALLING THE PreSet Plus WHEEL HUB ASSEMBLY	37
SERVICE PARTS	38
7. LUBRICATION	41
DRIVE HUB LUBRICATION	41
STEER AND TRAILER HUBS WITH OIL LUBRICANT	41
TRAILER HUBS WITH SEMI-FLUID GREASE LUBRICANT	41
8. BRAKE AND WHEEL INSTALLATION	43
CALIPER INSTALLATION	43
WHEEL INSTALLATION	43
HUB PILOT WHEEL MOUNTING SYSTEM	43
BALL SEAT WHEEL MOUNTING SYSTEM	44
9. WHEEL HUB AND ROTOR	46
WHEEL HUBS WITH CONMET DISC BRAKE ROTORS	46
Part Number Identification	46
Rotor Identification	46
10. HUB AND ROTOR INSPECTION	47
HAZARD ALERT MESSAGES	47
DISC BRAKE ROTOR INSPECTION	47
Heat Checks	47
Cracks	47
Deep Grooves or Scoring	48
Blue Marks or Bands	48
Polished Rotors	48
Martensite Spotted Rotors	48
Grease-Stained Rotors	48
Lining Transfer	49
Clogged or Restricted Vent Holes	49
Rotor Runout	49
Rotor Thickness	49
Rotor Resurfacing	50
11. HUB AND ROTOR REMOVAL AND DISC REPLACEMENT	51
HAZARD ALERT MESSAGES	51
HUB AND ROTOR REMOVAL	51
DISC BRAKE ROTOR REPLACEMENT	51
PART IDENTIFICATION	51
12. DISC BRAKE ROTOR REPLACEMENT	52
ROTOR REPLACEMENT PROCEDURES	52
ConMet Flat Rotors	52
ConMet Hat Rotor	63
ConMet U-Shaped Rotors	64
WHEEL HUB AND ROTOR – SERVICE PARTS LIST	68
WHEEL TORQUE SPECIFICATIONS	69


1. INTRODUCTION

ConMet offers three types of wheel hubs:

- Conventional hubs with manually-adjusted bearings
- PreSet hub assemblies with pre-adjusted bearings
- PreSet Plus hub assemblies with pre-adjusted bearings and an integrated spindle nut

Conventional Hubs


ConMet conventional hubs feature precision-machined aluminum or iron castings and are available in steer, drive and trailer configurations. Hubs are supplied with bearing cups and studs installed. Bearing cones and wheel seals are supplied by the customer. Bearings must be adjusted manually. See TMC RP618 for specifics of adjustment procedures.



Conventional Hub and Components
FIGURE 1

PreSet® Hub Assemblies

ConMet PreSet hub assemblies include precision-machined hubs, premium seals, specially toleranced roller bearings and unique precision-machined bearing spacers. This combination eliminates the need to manually adjust wheel end play. These components are delivered as a complete assembly, reducing the potential for premature failures due to incorrect end play settings and/or improper installation practices.




PreSet Hub and Components
FIGURE 2


PreSet Plus® Hub Assemblies

ConMet PreSet Plus hub assemblies feature the same PreSet technology and include the same precision-machined hubs, premium seals and specially toleranced roller bearings. However, PreSet Plus hubs incorporate the following:


- An integrated spindle nut that eases installation and disassembly and protects components during wheel end service
- An optimized spacer
- Standard magnetic fill plug




PreSet Plus Hub and Components
FIGURE 3




Steer Hub and Components
FIGURE 4



Drive Hub and Components
FIGURE 5



TN Trailer Hub and Components
FIGURE 6



TP Trailer Hub and Components
FIGURE 7

2. INSPECTION

HAZARD ALERT MESSAGES

Read and observe all hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.

WARNING

Do not work under a vehicle supported only by jacks. Jacks can slip and fall over. Serious personal injury and damage to components can result.

Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving. Support the vehicle with safety stands.

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

WHEEL END INSPECTION GENERAL GUIDELINES

NOTE

Operating temperature can be checked as the vehicle enters the service area following a normal run. If the hub is running in excess of 150°F above the ambient temperature in normal operating conditions, service is required.

Wheel end service and maintenance requirements will vary based on vehicle operating conditions, vehicle specifications, lubrication type, and vehicle performance history. Consolidated Metco recommends the maintenance schedule below, in conjunction with TMC RP631A, to be adjusted as needed for varying conditions.

CAUTION

If any item is found to be out of specification during any of the inspection steps listed below, place the vehicle out of service until the item can be repaired or replaced.

Driver Pre-Trip Visual Inspection

Visually inspect the vehicle prior to operation. Include the following items:

1. Check for loose, damaged, or missing fasteners on the wheel and hub cap or axle. Rust or dark streaks coming from the wheel bolts may be a sign of improper wheel bolt torque.
2. Check for loose, damaged, or missing hubcaps.
3. Check for lubricant leaks at:
 - Hubcap
 - Drive axle flange gasket
 - Oil fill plug
 - Oil seal leakage – indicated by lubricant on the hub, brake components or inside of the wheel
4. Check lubricant condition via hub cap window on steer and trailer hubs. Lubricant that is darkened, milky, shows water in it, or has large metallic particles in it is indicative of contamination or a part failure and must be replaced. Contaminated lubricant may be an indication of a leaking seal that should be replaced.
5. Check for insufficient lubricant level via hub cap window on steer and trailer hubs. Refill lubricant to the indicated fill level if required.

If any of the above conditions are found, place the vehicle out of service until the item can be repaired.

In Route Inspections

1. After making an in route stop, walk around the vehicle and inspect the hubs for any leaks (per item 3 under Driver Pre-Trip) and significant differences in temperature or excessive temperature. If excessive temperature is found, inspect and repair the wheel end as necessary. High temperatures and high loads may cause early bearing failure. Lubricant viscosity should be chosen based on expected operating temperatures.

Preventative Maintenance Schedule

During any routine preventative maintenance on the vehicle or axle (see your OEM guidelines and associated federal regulations), inspect the following items:

1. Check for loose, damaged, or missing fasteners on the wheel and hub cap. Rust or dark streaks coming from the wheel bolts may be a sign of improper wheel bolt torque.
2. Check for loose, damaged, or missing hubcaps.
3. Check for lubricant leaks at:
 - Hubcap
 - Drive axle flange gasket
 - Oil fill plug
 - Oil seal – indicated by lubricant on the hub, brake components or inside of the wheel
4. Check for insufficient lubricant level via hub cap window on steer and trailer hubs. Refill lubricant to the indicated fill level if required.

2. INSPECTION (CONTINUED)

5. Check the lubricant condition. Lubricant that is darkened, milky, shows water in it or has large metallic particles in it is indicative of contamination or a part failure and must be replaced. Contaminated lubricant may be an indication of a leaking seal that should be replaced.
 - On oil lubricated hubs equipped with a fill plug in the hubcap or barrel of the hub, place a magnet (or inspect the magnetic fill plug) in the lubricant and check for signs of large metallic particles picked up by the magnet. On drive axles, it is normal to find a small amount of very fine metallic particles from the carrier housing on the magnetic fill plug. These particles should be removed from the magnet anytime the plug is removed for inspection. If larger particles or chunks of metal are found, the hub should be removed from the spindle and the bearings and other components should be inspected for signs of damage or excessive wear.
 - In vehicles without a fill plug in drive hubs inspect the lubricant volume and condition from the fill plug in the axle carrier housing.
 - For vehicles lubricated with semi-fluid grease, inspect annually or every 100,000 miles. First, remove the hubcap and inspect the lubricant condition and volume. Verify the lubricant covers the ends of the bearing rollers. If the lubricant condition is good, add lubricant through the fill plug in the barrel of the hub to cover the ends of the

bearing rollers. If the lubricant has a dry and caked appearance, remove the wheel end from the vehicle and clean and inspect all components. Replace damaged or worn components as necessary. Refill hub with semi-fluid grease amount per chart on page 42.

6. If regular schedule maintenance requires wheels/axle to be lifted, perform steps 7 and 8.
7. Lift and support the axle (see figure 8). Rotate the wheel. Check that the wheel rotates freely and smoothly. Listen and feel for any signs of rough bearing operation or vibration.




FIGURE 8

8. Place your hand on the top of the tire and use a pry bar to lift the bottom of the tire to check for loose bearings or “chucking” (see figure 9). If excess movement or “chucking” is found, wheel end service is required.

NOTE

Before you check for chucking, be sure to grease the king pins.




FIGURE 9

If any of the above conditions are found, place the vehicle out of service until the item can be repaired.

Service Interval

Inspection results at driver pre-trip, in-route and preventative maintenance will indicate whether further service is required. When inspections indicate that service is necessary, follow the recommended service, inspection, reassembly and reinstallation instructions found in the following sections of this manual.

Lubrication Analysis

Beyond the recommended visual inspection and inspection with a magnet, develop a lubrication testing and replacement program. This program will depend on vehicle application, and lubrication type. A lubricant supplier should be consulted for additional lubricant inspection and testing recommendations.


3. IDENTIFICATION

WHEEL MOUNTING SYSTEMS

ConMet wheel hubs are available in both hub pilot and ball seat nut configurations.

Hub Pilot Wheel Mounting

The hub pilot wheel mounting system makes use of a single two-piece flange nut on each wheel stud for both single and dual wheel applications (see figure 10). The hub pilot wheel mounting system is also known as the Uni-Mount-10™ (10 stud), WHD-10™ (10 stud), WHD-8™ (8 stud), and ISO system.




Hub Pilot Mounting Systems
FIGURE 10

Ball Seat Wheel Mounting System

The ball seat wheel mounting system makes use of the spherical contact area between the nut and wheel to both locate the wheel and hold the wheel tight against the brake drum (see figure 11).

The ball seat wheel mounting system is also known as the stud piloted, ball seat cap nut (BCN) and double cap nut (DCN) system.



Ball Seat Mounting Systems
FIGURE 11

IDENTIFYING CONMET HUB ASSEMBLIES


Identifying your hub assembly is important for many reasons. It will enable you to properly service the hub assembly and purchase the appropriate replacement parts if needed. Plus, if a warranty issue arises, you'll then be able to provide details on all aspects of the ConMet hub. This section is devoted to finding and understanding the different identification numbers associated with ConMet hubs.

Vehicle Identification Number (VIN)

The quickest and easiest method of identifying your hub assembly is to note the vehicle identification number (VIN) and call the truck dealership. The dealership can then tell you what hubs were installed on your vehicle. If this is not possible, there is a variety of identification numbers located on a ConMet hub assembly.

Casting Number

This number is physically cast into the hub and appears in large characters usually on the back side of the mounting flange near the stud head (see figure 12).




Casting Number on the Back Side of the Mounting Flange
FIGURE 12

Machining Number


This number is stamped on one of the following:

- Mounting flange face (see figure 13)
- Diameter of the mounting flange (see figure 14)
- Back side of the mounting flange (see figure 15)
- Barrel of the hub (see figure 16)


The machining number represents the way the hub is machined (e.g., hub pilot vs. ball seat, 8.78" vs. 8.53" vs. 9" brake drum pilot diameter).



Mounting Flange Face
FIGURE 13



Mounting Flange Diameter
FIGURE 14




Mounting Flange Backface
FIGURE 15

3. IDENTIFICATION (CONTINUED)

Conventional Hubs


For instructions on installing ConMet's Conventional hub (see figure 17), refer to the Conventional reinstallation instructions in section 4.



Conventional Hub
FIGURE 17

PreSet® Hub Assemblies


For instructions on installing ConMet's PreSet hub assemblies (see figure 18), refer to the PreSet hub reinstallation instructions in section 5.



PreSet Hub Assembly
FIGURE 18

PreSet Plus® Hub Assemblies

For instructions on installing ConMet's PreSet Plus hub assemblies (see figure 19), refer to the PreSet hub assembly reinstallation instructions in section 6.




PreSet Plus Hub Assembly
FIGURE 19

4. CONVENTIONAL WHEEL HUBS – RECOMMENDED SERVICE

Conventional Hubs

ConMet conventional hubs feature precision-machined aluminum or iron castings and are available in steer, drive and trailer configurations. Hubs are supplied with bearing cups and studs installed. Bearing cones and seal are supplied by the customer. Bearings must be adjusted manually. See TMC RP618 specifics of adjustment procedures.



Conventional Hub and Components
FIGURE 20

When inspections indicate that service is necessary on a conventional hub, follow the recommended service, inspection, reassembly and installation instructions found in the following section.

HUB REMOVAL AND DISASSEMBLY

WARNING

Vehicles on jacks can fall, causing serious personal injury or property damage. Never work under a vehicle supported by a jack without supporting the vehicle with stands and blocking the wheels. Wear safe eye protection.

1. Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving.
2. Raise the axle until the tires are off the floor.

3. Place safety stands under the trailer frame or under each axle spring seat (see figure 21).




FIGURE 21

4. Remove the tire and wheel assembly using procedures specified by the wheel manufacturer (see figure 22).




FIGURE 22

WARNING

Sudden release of compressed air can cause serious personal injury and damage to components.

Before you service a spring chamber, carefully follow the manufacturer's instructions to compress and lock the spring to completely release the brake. Verify that no air pressure remains in the service chamber before you proceed.

5. If the axle is equipped with spring brake chambers, carefully compress and lock the springs so that they cannot actuate (see figure 23).





FIGURE 23

6. For drum brakes, remove the brake drum. Support the drum during the removal process to prevent damage to the components. For disc brakes, remove caliper per manufacturers' recommended procedure.

NOTE

If the hub to be disassembled is a drive hub, remove the drive axle shaft, and capture the oil (see figure 24).



Removing the Drive Axle Shaft
FIGURE 24

7. Place a container under the hubcap, or drive axle shaft for a drive hub, to receive the draining oil, then remove the hubcap or drive axle shaft. Do not reuse the oil. Correctly dispose of the lubricant.

8. Examine the spindle nut to determine the type of locking system. Disengage the locking device.

WARNING

Do not loosen the axle spindle nuts by either striking them directly with a hammer, or striking a drift or chisel placed against them. Damage to the parts will occur causing possible loss of axle wheel-end components and serious personal injury.

9. Remove the spindle nut system.

4. CONVENTIONAL WHEEL HUBS – RECOMMENDED SERVICE

10. Slide the hub off the spindle. Remove and save the outer bearing cone. Be careful when you remove the hub that you do not damage the outer bearing by dropping it on the floor.

- If the hub is difficult to remove because the seal or bearings are stuck on the spindle, use a mechanical puller to remove the hub (see figure 25).

- If part of the seal remains on the spindle, carefully remove the part of the seal that remains on the spindle.

NOTE

This can be done by striking the remaining portion of the seal with the round end of a ball-peen hammer. Use caution not to damage the seal journal on the spindle.





FIGURE 25

11. Place the hub on its outboard end and remove the seal. Retain the seal if it needs to be returned for warranty consideration.

12. Remove the inner bearing cone (see figure 26).



Hub Disassembly
FIGURE 26

COMPONENT INSPECTION AND REPLACEMENT HAZARD ALERT MESSAGES

WARNING

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

Observe all warnings and cautions provided by the press manufacturer to avoid damage to components and serious personal injury.

Do not hit steel parts with a steel hammer. Pieces of a part can break off. Serious personal injury and damage to components can result. Use a brass or synthetic mallet for assembly and disassembly procedures.

Solvent cleaners can be flammable, poisonous and cause burns. Examples of solvent cleaners are carbon tetrachloride, and emulsion-type and petroleum-base cleaners. Read the manufacturer's instructions before using a solvent cleaner, then carefully follow the instructions. Also follow the procedures below.

- Wear safe eye protection.
- Wear clothing that protects your skin.
- Work in a well-ventilated area.
- Do not use gasoline or solvents that contain gasoline. Gasoline can explode.
- You must use hot solution tanks or alkaline solutions correctly. Read the manufacturer's instructions before using hot solution tanks and alkaline solutions. Then carefully follow the instructions.

CAUTION

Do not use hot solution tanks or water and alkaline solutions to clean ground or polished parts. Damage to parts can result.

CLEAN AND DRY COMPONENTS

Worn or Damaged Components

WARNING

Do not repair or recondition wheel-end components. Replace damaged, worn or out-of-specification components. Do not mill or machine any components. Using repaired, reconditioned, damaged or worn components can cause wheel end failure, which can result in serious injury and property damage.

Hub and Component Cleaning

1. Use a cleaning solvent to clean the hub and all wheel end components.
2. Do NOT clean ground or polished parts in a hot solution tank or with water, steam or alkaline solutions. These solutions will cause corrosion of the parts.
3. Clean and inspect the wheel bearing cups and cones, race, spindle bearing and seal journals on the spindle and hub. Bearings should be cleaned with clean filtered solvent and dried with either compressed air or a lint-free rag.

CAUTION

If compressed air is used, do not spin dry the bearings. The rollers may score due to lack of lubricant and rollers could come off which can result in serious injury. Ensure that the air line is moisture free.

4. Clean and inspect the spindle. Be sure to clean the full length of the seal journal on the spindle.
5. Parts must be dried immediately after cleaning. Dry parts with clean paper towels or rags, or compressed air. Do not dry bearings by spinning with compressed air.

4. CONVENTIONAL WHEEL HUBS — RECOMMENDED SERVICE

- Apply a light oil to cleaned and dried parts that are not damaged and are to be immediately assembled. Use only the type of oil used by the manufacturer. Do NOT apply oil to the brake linings or the brake drums.
- If the parts are to be stored, apply a good corrosion preventative to all surfaces. Do NOT apply the material to the brake linings or the brake drums. Store the parts inside special paper or other material that prevents corrosion.

INSPECTING BEARING CUPS AND CONES



If you choose to reuse existing bearings at this service, they must be inspected in accordance with the bearing manufacturers recommended guidelines.



If this inspection indicates that existing bearing component(s) must be replaced, bearing cups and cones must be replaced as a set.


After components have been properly cleaned, visually inspect the cups and cones for any wear or damage. Reference TMC RP644 for proper component inspection procedures.

REMOVING CUPS IN ALUMINUM HUBS

- If the bearing cup must be removed from an aluminum hub, remove it by welding a large bead around the bearing surface of the steel cup, letting the assembly cool, and removing the bearing cup (see figure 27).

NOTE

If a welder is not available, heat the hub in an oven to a temperature not to exceed 300°F and pound out the bearing cups with a hammer and mild steel bar, being careful not to damage the hub.



Welding Bead
FIGURE 27

- Inspect the bearing cup bore for evidence of cup rotation or spun cups.
 - If cup rotation exists, replace the hub.

REMOVING CUPS IN IRON HUBS

- On an iron hub, remove the bearing cup using a large hammer and a mild steel bar or a hydraulic press. Take precaution to avoid damaging the bearing cup bore and shoulder.
- Inspect the bearing cup bore for evidence of cup rotation or spun cups.
 - If cup rotation exists, replace the hub.

INSTALLING A NEW CUP IN ALUMINUM HUBS

To install a new cup in an aluminum hub, it is recommended that the hub be heated in boiling water (212°F) or in an oven at a temperature not to exceed 300°F. Cooling the cup in a freezer to 32°F or below will further ease the installation.




Do not overheat the hub as it may degrade the heat-treated strength of the hub. Do not heat the hub with a torch or open flame.

Remove the aluminum hub from the oven or water and carefully drop in the new bearing cup being certain it is fully seated. If the cup is loose, allow a few seconds for it to heat up and secure itself before moving the hub. Use a 0.001" to 0.002" feeler gauge to ensure the cup is fully seated against the shoulder of the bearing bore.

INSTALLING A NEW CUP IN IRON HUBS

Iron hubs do not need to be heated for bearing cup installation. Press the bearing cup into the hub, being certain that it is fully seated (see figure 28). Use a 0.001" to 0.002" feeler gauge to ensure the cup is fully seated against the shoulder of the bearing bore.



Bearing Cup Pressed into Hub
FIGURE 28

4. CONVENTIONAL WHEEL HUBS — RECOMMENDED SERVICE

WHEEL STUDS

Replace all wheel studs that have damaged or distorted threads, are broken or bent, or are badly corroded. Also, replace both studs adjacent to the damaged stud. If two or more studs have damage, replace all the studs in the hub. Broken studs are usually an indication of excessive or inadequate wheel nut torque.

STUD REMOVAL



Observe all warnings and cautions for press operation provided by the press manufacturer to avoid serious personal injury and damage to components.

- Place the clean hub in a shop press with the hub supported evenly around and adjacent to the stud being removed.



Failure to adequately support the hub can result in physical injury and/or damage to the hub.

Some hubs are configured so it is impractical to have supports to prevent the hub from tipping when force is applied to the stud. In this case, support the hub on wood blocks on the floor and use a heavy hammer to drive the studs out with several sharp blows. Be careful to avoid damaging the hub and components, particularly the seal bore and the ABS tone ring.

- Press the stud out of the hub.

STUD REPLACEMENT



On the ball seat wheel mounting system, always use left-handed threaded studs, which are gold in color and have an "L" stamped on the end, in the hub on the driver's side of the equipment, and use right-handed threaded studs, which are silver in color and have an "R" stamped on the end, in the hub on the passenger's side of the equipment. The ConMet part number is located on the head of the stud. The same part number must be used for replacement unless changing the drum or wheel type.

- To install a new stud, support the hub evenly around and adjacent to the stud being installed.
- Press the new stud all the way into the hub. Be sure the stud is fully seated and that the stud head is not embedded into the hub.



Excessive force can cause the stud head to be embedded into the hub, which can create a crack in the hub, resulting in serious injury and property damage. If a stud head is embedded in a hub, replace the hub.

HUB, DRUM AND WHEEL INSPECTION

- Inspect the drum pilots, wheel pilots, and mounting face on the hub for damage. A damaged drum pilot is usually caused by improper drum mounting. A damaged wheel pilot could be the result of inadequate wheel nut torque, allowing the wheels to slip in service. Also, inspect other surfaces of the hub for signs of cracks or damage.
- Inspect the wheels and brake drum for damage.



Do not repair or recondition wheel-end components. Replace damaged, worn or out-of-specification components. Do not mill or machine any components. Using repaired, reconditioned, damaged or worn components can cause wheel end failure, which can result in serious injury and property damage.

ABS TONE RING INSPECTION (AS APPLICABLE)

The Anti-Lock Braking System (ABS) signals acts like any signal generator where the magnet passes a coil and generates a current. On hubs, the toothed ring passes a sensor and generates a signal that is sent to the ABS computer. There are three types of ABS rings used on ConMet hubs — machined, stamped steel and bolt on (see figure 29).





FIGURE 29

If the tone ring is damaged (for example, if it is dropped, bent, chipped or dinged), it must be replaced. For a list of replacement ABS rings, refer to the Service Parts List in the back of this section.

4. CONVENTIONAL WHEEL HUBS – RECOMMENDED SERVICE

REMOVAL AND INSTALLATION OF MACHINED ABS TONE RING


For a machined ring, remove using a chisel, making sure not to damage the hub (see figure 30). Reinstall by heating the ring to 350°F in an oven and installing it on the hub.




Machined ABS Ring
FIGURE 30

REMOVAL AND INSTALLATION OF STAMPED STEEL ABS TONE RING

- 1. The steer axle tone ring can be removed by gripping the ring with a pair of locking pliers and tapping the pliers upward with a rubber mallet. Work around the ring to keep the ring from cocking (see figure 31). Drive axle and trailer tone rings can be removed by gripping the ring with a pair of locking pliers and prying against the head of a wheel stud to lift the ring off the hub. Work around the ring to prevent cocking (see figure 32).



Stamped Steel ABS Ring
FIGURE 31



Stamped Steel ABS Ring
FIGURE 32

- 2. Thoroughly clean and degrease the ABS ring seat on the hub with a nonflammable solvent.


CAUTION

Replace the hub if the ABS ring seat is damaged.
The ABS ring must be fully seated with a maximum of 0.008" axial runout to ensure the ABS system functions properly.

NOTE


For steer hubs, be certain the inside diameter flange is facing up.

- 3. Place the hub in a press and place the ABS ring on the hub ring seat.
- 4. Using ConMet ring installation tool (part number 107119), center the tool over the ABS ring. Each type of ring fits a corresponding diameter on the tool (see figure 33).



Installing the ABS Tone Ring
FIGURE 33

- 5. Press the ring on the hub. If a press is not available, drive the ring on with a hammer or mallet until the ring seats on the hub (see figure 34). A swift initial blow with an 8-lb. hammer may be necessary to start the ring onto the hub.



Using a Hammer to Install the Ring
FIGURE 34

- 6. Inspect the ring to ensure proper seating. If the ring is not completely seated, continue to drive the ring with the ring installation tool until it is completely seated.

REMOVAL AND INSTALLATION OF BOLT ON ABS TONE RINGS

- 1. Remove and discard the fasteners holding the ABS tone ring on the hub.
- 2. Thoroughly clean and degrease the ABS ring seat on the hub with a non-flammable solvent.
- 3. Install the new ABS ring using the new fasteners included with the ring. Torque the fasteners to the torque specifications below.

Thread Size	Torque
#8-32	18-22 in-lbs
1/4"-20	155-165 in-lbs


4. CONVENTIONAL WHEEL HUBS – REASSEMBLY

CONVENTIONAL WHEEL HUBS REASSEMBLY

CAUTION

When using an oil bath system, do not pack the bearing with grease. Grease will prevent the proper circulation of axle lubricant and can cause premature wheel seal and bearing failure.

- 1. Place the hub, seal end up, on a clean work bench surface.
- 2. Lubricate the inner bearing cone with the same lubricant as will be used in the hub and install it into the inner bearing cup (see figure 35).



Bearing Cone Assembly
FIGURE 35

NOTE

The seal must be replaced every time the hub is removed from the spindle.
Do not apply any gasket sealant to the seal outer or inner diameter.
Always use the seal installation tool specified by the seal manufacturer. Using an improper tool can distort or damage the seal and cause premature seal failure.

- 3. Position the seal into the hub bore. Use a ConMet seal installation tool or flat plate and a small mallet to install the seal.

NOTE

ConMet seals require the proper tool for installation. Refer to the tables below for a ConMet seal installation tool or flat plate dimensions. For other seals, refer to the specific manufacturers' instructions.


ConMet Seal Installation Tools

Axle Type	Part Number
FF Steer	10084010
FL Steer	10084011
R-Drive	10084012
TN-Trailer	10084013
TP-Trailer	10084013

Flat Plate Dimensions

Application	Seal Part Number	Min. Dia.	Max. Dia.
FF Steer	10045885	4.45"	4.65"
FL Steer	10045883	5.2"	5.4"
R-Drive	10045887	5.6"	5.85"
TN-Trailer	10045888	5.6"	5.85"
TP-Trailer	10045889	5.6"	5.85"

- 4. When installing the ConMet seal, tap the adapter plate of the installation tool around the outer edge to position the seal. Drive the wheel seal into place (see figure 36). Once the tool bottoms out, the seal is installed correctly.




ConMet Seal Installation
FIGURE 36

- 5. Check to be certain the seal is not cocked and that the seal inner diameter and the inner bearing turn freely.

CAUTION

Failure to lubricate the inner diameter of the seal may result in premature seal failure.

- 6. Lubricate the inner diameter of the seal with a light film of the same lubricant as will be used in the hub.
- 7. Turn the hub over, and place it seal end down.
- 8. Lubricate the outer bearing cone with the same lubricant as will be used in the hub and install it into the hub assembly (see figure 37).



Installing the Outer Bearing Cone
FIGURE 37

4. CONVENTIONAL WHEEL HUBS — REINSTALLATION

INSTALLING ConMet CONVENTIONAL WHEEL HUBS

Spindle Preparation

1. Clean the spindle to remove any lubricant, corrosion prevention coating, foreign material, or surface rust that may be present. Be sure to clean the full length of the seal journal.
2. Lubricate the bearing journals on the spindle, or the inside diameter of the bearing cones with Grade 2 grease or the lubricant that will be used in the wheel end. Do not coat the seal journal on the spindle.
3. Lubricate the inside diameter of the seal with the same lubricant that will be used in the wheel end.

CAUTION

Failure to apply lubricant to the bearing journals will result in fretting corrosion, which may result in difficulty removing the bearing. Never support the hub on the spindle with just the inner bearing and seal. This can damage the seal and cause premature failure, i.e., by cocking the seal in the bore.

Conventional Hub Installation

NOTE

Existing spindle nuts can be re-used as long as they are in good condition. Do not re-use a spindle nut that is worn or pitted on its face or threads.

NOTE

See TMC RP618 for more details regarding installation of wheel hubs with manual adjusted bearing systems.

NOTE

The following service procedures apply to steer, drive, and trailer axle assemblies using conventional double nut or single nut systems. For self-locking single nut systems, consult manufacturers' instructions.

1. Lubricate the bearings with clean lubricant of the same type used in the axle sump or hub assembly.
2. Install the wheel hub and bearing onto the axle spindle with a smooth, firm motion. Use care to maintain alignment between the bearing cones, and spindle to avoid seal damage. Torque the inner adjusting nut to 200 ft-lbs while rotating the hub assembly.
3. Back off the inner adjusting nut one full turn. Rotate the hub.
4. Re-torque the inner adjusting nut to 50 ft-lbs while rotating the wheel hub assembly.
5. Back off the inner adjustment nuts as per the Manual Bearing Adjustment Procedure table (next page).
6. Install the locking washer.

NOTE

If dowel pin and washer (or washer tang and nut flat) are not aligned, remove the washer, turn it over, and reinstall. If required, loosen the inner (adjusting) nut just enough for alignment.

NOTE

Bendable type washer lock only: Secure nuts by bending one wheel nut washer tang over the inner and outer nut. Bend the tangs over the closest flat perpendicular to the tang.

7. Install and torque the outer jam nut as per chart on next page.

NOTE

If end play is not within specification, readjustment is required. Be sure to install or activate any locking device.

NOTE

This information is intended for reference only. Consolidated Metco inc. does not assume any liability in the event of improper use or mismatch of components. For additional information, see TMC RP618.

8. Use a dial indicator to verify acceptable endplay of 0.001"-0.005".

4. CONVENTIONAL WHEEL HUBS — REINSTALLATION

Manual Bearing Adjustment Procedure (reference TMC RP618)

Axle Type	Axle Spindle Threads per Inch	Spindle Nut Type	Final Spindle Nut Backoff	Jam Nut Torque (ft-lbs)
Steer (front non-drive)	12	Single Nut with Cotter Pin	1/6 Turn	Install Cotter Pin to Lock Spindle Nut into Position (from step 6)
	18		1/4 Turn	
	12	Double Nut System With Bendable Tang Washer or Dowel Pin and Washer	1/3 Turn	200-300
	14		1/2 Turn	
Drive	18	Double Nut System Dowel Pin and Washer	1/4 Turn	300-400
	12			
	14	Double Nut System with Bendable Tang Washer	1/4 Turn	200-275
	16			
Trailer	12	Double Nut System with Bendable Tang Washer or Dowel Pin and Washer	1/4 Turn	200-300
	16			

4. CONVENTIONAL WHEEL HUBS – SERVICE PARTS

Axle Designations

Designation	Typical Axle Rating (lbs)	Comments
Steer Axle		
FC Steer	8,000	Medium duty
FF Steer	12,000-14,700	Standard linehaul axle. Comes in two spindle variations. 1. Flat locking feature with 12 threads/inch. 2. Keyway locking feature with 18 threads/inch.
FL Steer	20,000	Vocational applications
Drive Axle		
L-Drive	19,000	Medium duty
R-Drive	20,000-23,000	Standard linehaul axle
Trailer Axle		
TN Trailer	22,500	Tapered spindle
TP Trailer	25,000	Parallel spindle or "Propar"

NOTE: These axle ratings are to be used as a reference only. Refer to the vehicle's door plate for your specific application.

ConMet Seals

Position	Spindle Type	Aftermarket Part Number
Steer	FF Spindle	10045885
	FL Spindle	10045883
Drive	R Spindle	10045887
Trailer	TP Spindle	10045889
	TN Spindle	10045888

ConMet Seal Installation Tools

Axle Designation	Installation Tool Part Number	Min. Dia.*	Max. Dia.*
FF Steer	10084010	4.45"	4.65"
FL Steer	10084011	5.2"	5.4"
R-Drive	10084012	5.6"	5.85"
TN Trailer	10084013		
TP Trailer	10084013		

*Required flat plate dimensions if you are not using a ConMet installation tool (minimum of 3/8", 9.5 mm thick).

4. CONVENTIONAL WHEEL HUBS – SERVICE PARTS

Approved Conventional Aftermarket Bearings

Description	ConMet Number	Bearing Set Number
FC Steer Axle		
Inner Cup & Cone	10037695	Not available in sets
Outer Cup & Cone	10037696	
FF Steer Axle		
Inner Cup & Cone	10041905	Set 413
Outer Cup & Cone	10041906	Set 406
FL Steer Axle		
Inner Cup & Cone	10041925	Set 423
Outer Cup & Cone	10041926	Set 424
L-Drive Axle		
Inner Cup & Cone	10037959	Not available in sets
Outer Cup & Cone	10037960	
R-Drive Axle		
Inner Cup & Cone	10041915	Set 403
Outer Cup & Cone	10041916	Set 401
TN Trailer Axle		
Inner Cup & Cone	10041935	Set 414
Outer Cup & Cone	10041905	Set 413
TP Trailer Axle		
Inner Cup & Cone	10041945	Set 415
Outer Cup & Cone	10041945	Set 415

4. CONVENTIONAL WHEEL HUBS – SERVICE PARTS

ABS Rings for ConMet Hubs (for reference only)

Axle	Material	Type of Brake	Hub Casting Number	ABS Ring Part Number
FC Steer	Iron	Drum	10016569	10016586
FF Steer	Aluminum	Disc	10016331	10009780
			10018723	10009780
			10020207	10009780
			101945	10009780
		Drum	103110	10009780
			104112	10009780
	Iron	Disc	10000776	10009780
			10011945	10009780
			10019965	10023558
FL	Aluminum	Drum	10005604	10009780
	Iron	Disc	10012265	10019840
L-Drive (190)	Iron	Disc	10005561	107912
		Drum	10020602	10023559
R-Drive	Aluminum	Disc	10020627	10023757
		Drum	10016328	103705
	Iron	Drum	10001280	103705
			10001387	103705
			10018310	103705
			10018311	103705
TN	Aluminum	Drum	10018311	103705
TP	Aluminum	Disc	102035	105459
		Drum	10016620	10019896
	Iron	Drum	10001216	105459
			10025633	10023829


NOTE

If an ABS ring is not listed for a particular hub, contact ConMet Customer Service at 800-547-9473.

5. PRESet WHEEL HUBS – RECOMMENDED SERVICE

PreSet Hub Assemblies

ConMet PreSet hub assemblies include precision-machined hubs, premium seals, specially toleranced roller bearings and unique precision-machined bearing spacers. This combination eliminates the need to manually adjust wheel end play. These components are delivered as a complete assembly, reducing the potential for premature failures due to incorrect end play settings and/or improper installation practices.



PreSet Hub and Components
FIGURE 38

When inspections indicate that service is necessary on a PreSet Hub, follow the recommended service, inspection, reassembly and reinstallation instructions found in the following section.

In order to ensure optimum wheel hub performance, ConMet recommends that only approved PreSet service parts be used to replace all critical components of the system. Refer to the back of this section for a listing of approved parts.

HUB REMOVAL AND DISASSEMBLY

WARNING

Vehicles on jacks can fall, causing serious personal injury or property damage. Never work under a vehicle supported by a jack without supporting the vehicle with stands and blocking the wheels. Wear safe eye protection.

1. Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving.
2. Raise the axle until the tires are off the floor.
3. Place safety stands under the trailer frame or under each axle spring seat (see figure 39).




FIGURE 39

4. Remove the tire and wheel assembly using procedures specified by the wheel manufacturer (see figure 40).




FIGURE 40

WARNING

Sudden release of compressed air can cause serious personal injury and damage to components. Before you service a spring chamber, carefully follow the manufacturer's instructions to compress and lock the spring to completely release the brake. Verify that no air pressure remains in the service chamber before you proceed.

5. If the axle is equipped with spring brake chambers, carefully compress and lock the springs so that they cannot actuate (see figure 41).





FIGURE 41

6. For drum brakes, remove the brake drum. Support the drum during the removal process to prevent damage to the components. For disc brakes, remove caliper per manufacturers' recommended procedure.

NOTE

If the hub to be disassembled is a drive hub, remove the drive axle shaft, and capture the oil (see figure 42).



Removing the Drive Axle Shaft
FIGURE 42

5. PRESet WHEEL HUBS – RECOMMENDED SERVICE

7. Place a container under the hubcap, or drive axle shaft for a drive hub, to receive the draining oil, then remove the hubcap or drive axle shaft. Do not reuse the oil. Correctly dispose of the lubricant.

8. Examine the spindle nut to determine the type of locking system. Disengage the locking device.

WARNING

Do not loosen the axle spindle nuts by either striking them directly with a hammer, or striking a drift or chisel placed against them. Damage to the parts will occur causing possible loss of axle wheel-end components and serious personal injury.

9. Remove the spindle nut system.

10. Slide the hub off the spindle. Remove and save the outer bearing cone. Be careful when you remove the hub that you do not damage the outer bearing by dropping it on the floor.

- If the hub is difficult to remove because the seal or bearings are stuck on the spindle, use a mechanical puller to remove the hub (see figure 43).

- If part of the seal remains on the spindle, carefully remove the part of the seal that remains on the spindle.

NOTE

This can be done by striking the remaining portion of the seal with the round end of a ball-peen hammer. Use caution not to damage the seal journal on the spindle.





FIGURE 43

11. Place the hub on its outboard end and remove the seal. Retain the seal if it needs to be returned for warranty consideration.

12. Remove the inner bearing cone and spacer (see figure 44).



Hub Disassembly
FIGURE 44

COMPONENT INSPECTION AND REPLACEMENT HAZARD ALERT MESSAGES

Read and observe all hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.

WARNING

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

Observe all warnings and cautions provided by the press manufacturer to avoid damage to components and serious personal injury.

Do not hit steel parts with a steel hammer. Pieces of a part can break off. Serious personal injury and damage to components can result. Use a brass or synthetic mallet for assembly and disassembly procedures.

Solvent cleaners can be flammable, poisonous and cause burns. Examples of solvent cleaners are carbon tetrachloride, and emulsion-type and petroleum-base cleaners. Read the manufacturer's instructions before using a solvent cleaner, then carefully follow the instructions. Also follow the procedures below.

- Wear safe eye protection.
- Wear clothing that protects your skin.
- Work in a well-ventilated area.
- Do not use gasoline or solvents that contain gasoline. Gasoline can explode.
- You must use hot solution tanks or alkaline solutions correctly. Read the manufacturer's instructions before using hot solution tanks and alkaline solutions. Then carefully follow the instructions.

CAUTION

Do not use hot solution tanks or water and alkaline solutions to clean ground or polished parts. Damage to parts can result.

5. PRESet WHEEL HUBS – RECOMMENDED SERVICE

CLEAN AND DRY COMPONENTS

Worn or Damaged Components

WARNING

Do not repair or recondition wheel-end components. Replace damaged, worn or out-of-specification components. Do not mill or machine any components. Using repaired, reconditioned, damaged or worn components can cause wheel end failure, which can result in serious injury and property damage.

Hub and Component Cleaning

1. Use a clean filtered solvent to clean the hub and all wheel end components.
2. Do NOT clean ground or polished parts in a hot solution tank or with water, steam or alkaline solutions. These solutions will cause corrosion of the parts.
3. Clean and inspect the wheel bearing cups and cones, race, spindle bearing and seal journals on the spindle and hub. Bearings should be cleaned with clean filtered solvent and dried with either compressed air or a lint-free rag.

CAUTION

If compressed air is used, do not spin dry the bearings. The rollers may score due to lack of lubricant and rollers could come off which can result in serious injury. Ensure that the air line is moisture free.

4. Clean and inspect the spindle. Be sure to clean the full length of the seal journal on the spindle.
5. Parts must be dried immediately after cleaning. Dry parts with clean paper towels or rags, or compressed air. Do not dry bearings by spinning with compressed air.

6. Apply a light oil to cleaned and dried parts that are not damaged and are to be immediately assembled. Use only the type of oil used by the manufacturer. Do NOT apply oil to the brake linings or the brake drums.

7. If the parts are to be stored, apply a good corrosion preventative to all surfaces. Do NOT apply the material to the brake linings or the brake drums. Store the parts inside special paper or other material that prevents corrosion.

INSPECTING BEARING CUPS AND CONES AND BEARING SPACER

NOTE

PreSet and PreSet Plus hubs use a precision-machined spacer in conjunction with specially tolerated bearings to control wheel end play. ConMet recommends installing a new PreSet/PreSet Plus service kit when inspection indicates that component replacement is necessary. PreSet/PreSet Plus service kits are available from a parts dealer or distributor.

CAUTION

If you choose to reuse existing bearings at this service, they must be inspected in accordance with the bearing manufacturers recommended guidelines.


CAUTION

If this inspection indicates that existing bearing component(s) must be replaced, bearing cups and cones must be replaced as a set. Whenever new bearings are installed, replacement of the bearing spacer is also recommended.

1. After components have been properly cleaned, visually inspect the cups, cones and spacer for any wear or damage. Reference TMC RP644 for

proper component inspection procedures.

Bearing spacers should be visually inspected for signs of wear or damage. Carefully inspect the machined ends of the bearing spacer. Wear to the bearing spacer can appear as a sharp ring of standing metal at either edge of the machined surfaces (see figure 45). Replace the spacer if it has visible wear evidenced by a raised edge on the machined end.



Bearing Spacer Wear
FIGURE 45

2. If removal or replacement is required, follow the steps outlined below.


REMOVING CUPS IN ALUMINUM HUBS

1. If the bearing cup must be removed from an aluminum hub, remove it by welding a large bead around the bearing surface of the steel cup, letting the assembly cool, and removing the bearing cup (see figure 46).

NOTE

If a welder is not available, heat the hub in an oven to a temperature not to exceed 300°F and pound out the bearing cups with a hammer and mild steel bar, being careful not to damage the hub.

5. PRESET WHEEL HUBS — RECOMMENDED SERVICE



Welding Bead
FIGURE 46

- Inspect the bearing cup bore for evidence of cup rotation or spun cups.
 - If cup rotation exists, replace the hub.

REMOVING CUPS IN IRON HUBS

- On an iron hub, remove the bearing cup using a large hammer and a mild steel bar or a hydraulic press. Take precaution to avoid damaging the bearing cup bore and shoulder.
- Inspect the bearing cup bore for evidence of cup rotation or spun cups.
 - If cup rotation exists, replace the hub.

INSTALLING A NEW CUP IN ALUMINUM HUBS

To install a new cup in an aluminum hub, it is recommended that the hub be heated in boiling water (212°F) or in an oven at a temperature not to exceed 300°F. Cooling the cup in a freezer to 32°F or below will further ease the installation.




Do not overheat the hub as it may degrade the heat-treated strength of the hub. Do not heat the hub with a torch or open flame.

Remove the aluminum hub from the oven or water and carefully drop in the new bearing cup being certain it is fully seated. If the cup is loose, allow a few seconds for it to heat up and secure itself before moving the hub. Use a 0.001" to 0.002" feeler gauge to ensure the cup is fully seated against the shoulder of the bearing bore.

INSTALLING A NEW CUP IN IRON HUBS

Iron hubs do not need to be heated for bearing cup installation. Press the bearing cup into the hub, being certain that it is fully seated (see figure 47). Use a 0.001" to 0.002" feeler gauge to ensure the cup is fully seated against the shoulder of the bearing bore.



Bearing Cup Pressed into Hub
FIGURE 47

WHEEL STUDS

Replace all wheel studs that have damaged or distorted threads, are broken or bent, or are badly corroded. Also, replace both studs adjacent to the damaged stud. If two or more studs have damage, replace all the studs in the hub. Broken studs are usually an indication of excessive or inadequate wheel nut torque.

STUD REMOVAL



Observe all warnings and cautions for press operation provided by the press manufacturer to avoid serious personal injury and damage to components.

- Place the clean hub in a shop press with the hub supported evenly around and adjacent to the stud being removed.



Failure to adequately support the hub can result in physical injury and/or damage to the hub.

Some hubs are configured so it is impractical to have supports to prevent the hub from tipping when force is applied to the stud. In this case, support the hub on wood blocks on the floor and use a heavy hammer to drive the studs out with several sharp blows. Be careful to avoid damaging the hub and components, particularly the seal bore and the ABS tone ring.

- Press the stud out of the hub.

STUD REPLACEMENT



On the ball seat wheel mounting system, always use left-handed threaded studs, which are gold in color and have an "L" stamped on the end, in the hub on the driver's side of the equipment, and use right-handed threaded studs, which are silver in color and have an "R" stamped on the end, in the hub on the passenger's side of the equipment. The ConMet part number is located on the head of the stud. The same part number must be used for replacement unless changing the drum or wheel type.

- To install a new stud, support the hub evenly around and adjacent to the stud being installed.
- Press the new stud all the way into the hub. Be sure the stud is fully seated and that the stud head is not embedded into the hub.

5. PRESET WHEEL HUBS — RECOMMENDED SERVICE



Excessive force can cause the stud head to be embedded into the hub, which can create a crack in the hub, resulting in serious injury and property damage. If a stud head is embedded in a hub, replace the hub.

HUB, DRUM AND WHEEL INSPECTION

- Inspect the drum pilots, wheel pilots, and mounting face on the hub for damage. A damaged drum pilot is usually caused by improper drum mounting. A damaged wheel pilot could be the result of inadequate wheel nut torque, allowing the wheels to slip in service. Also, inspect other surfaces of the hub for signs of cracks or damage.
- Inspect the wheels and brake drum for damage.



Do not repair or recondition wheel-end components. Replace damaged, worn or out-of-specification components. Do not mill or machine any components. Using repaired, reconditioned, damaged or worn components can cause wheel end failure, which can result in serious injury and property damage.

ABS TONE RING INSPECTION (AS APPLICABLE)

The Anti-Lock Braking System (ABS) signals acts like any signal generator where the magnet passes a coil and generates a current. On hubs, the toothed ring passes a sensor and generates a signal that is sent to the ABS computer. There are three types of ABS rings used on ConMet hubs — machined, stamped steel and bolt on (see figure 48).





FIGURE 48

If the tone ring is damaged (for example, if it is dropped, bent, chipped or dinged), it must be replaced. For a list of replacement ABS rings, refer to the Service Parts List in the back of this section.

REMOVAL AND INSTALLATION OF MACHINED ABS TONE RING


For a machined metal ring, remove using a chisel, making sure not to damage the hub (see figure 49). Reinstall by heating the ring to 350°F in an oven and installing it on the hub.




Machined ABS Ring
FIGURE 49

REMOVAL AND INSTALLATION OF STAMPED STEEL ABS TONE RING

- The steer axle tone ring can be removed by gripping the ring with a pair of locking pliers and tapping the pliers upward with a rubber mallet. Work around the ring to keep the ring from cocking (see figure 50). Drive axle and trailer tone rings can be removed by gripping the ring with a pair of locking pliers and prying against the head of a wheel stud to lift the ring off the hub. Work around the ring to prevent cocking (see figure 51).



Stamped Steel ABS Ring
FIGURE 50



Stamped Steel ABS Ring
FIGURE 51

- Thoroughly clean and degrease the ABS ring seat on the hub with a nonflammable solvent.




Replace the hub if the ABS ring seat is damaged.
The ABS ring must be fully seated with a maximum of 0.008" axial runout to ensure the ABS system functions properly.

5. PRESET WHEEL HUBS – RECOMMENDED SERVICE

NOTE


For steer hubs, be certain the inside diameter flange is facing up.

- 3. Place the hub in a press and place the ABS ring on the hub ring seat.
- 4. Using ConMet ring installation tool (part number 107119), center the tool over the ABS ring. Each type of ring fits a corresponding diameter on the tool (see figure 52).



Installing the ABS Tone Ring
FIGURE 52

- 5. Press the ring on the hub. If a press is not available, drive the ring on with a hammer or mallet until the ring seats on the hub (see figure 53). A swift initial blow with an 8-lb. hammer may be necessary to start the ring onto the hub.



Using a Hammer to Install the Ring
FIGURE 53

- 6. Inspect the ring to ensure proper seating. If the ring is not completely seated, continue to drive the ring with the ring installation tool until it is completely seated.

REMOVAL AND
INSTALLATION OF BOLT
ON ABS TONE RINGS (For
Disc Brakes)

- 1. Remove and discard the fasteners holding the ABS tone ring on the hub.
- 2. Thoroughly clean and degrease the ABS ring seat on the hub with a non-flammable solvent.
- 3. Install the new ABS ring using the new fasteners included with the ring. Torque the fasteners to the torque specifications below.

Thread Size	Torque
#8-32	18-22 in-lbs
1/4"-20	155-165 in-lbs

5. PRESET WHEEL HUBS – REASSEMBLY

PreSet WHEEL HUBS

CAUTION


When using an oil bath system, do not pack the bearing with grease. Grease will prevent the proper circulation of axle lubricant and can cause premature wheel seal and bearing failure.

- 1. Place the hub, seal end up, on a clean work bench surface.

NOTE


If you are working on a drive or trailer hub, go to step 3. If you are working on a steer hub, proceed as follows.

- 2. For steer hubs, install the tubular bearing spacer with the tapered end down (see figure 54).



Bearing Cone Assembly
FIGURE 54

- 3. Lubricate the inner bearing cone with the same lubricant as will be used in the hub and install it into the inner bearing cup (see figure 55).



Bearing Cone Assembly
FIGURE 55

NOTE

The seal must be replaced every time the hub is removed from the spindle. Do not apply any gasket sealant to the seal outer or inner diameter. Always use the seal installation tool specified by the seal manufacturer. Using an improper tool can distort or damage the seal and cause premature seal failure.

- 4. Position the seal into the hub bore. Use a ConMet seal installation tool or flat plate and a small mallet to install the seal.

NOTE

ConMet seals require the proper tool for installation. Refer to the table below for a ConMet seal installation tool or flat plate dimensions. For other seals, refer to the specific manufacturers' instructions.

ConMet Seal Installation Tools

Axle Type	Part Number
FF Steer	10084010
FL Steer	10084011
R-Drive	10084012
TN Trailer	10084013
TP Trailer	10084013

Flat Plate Dimensions

Application	Seal Part Number	Min. Dia.	Max. Dia.
FF Steer	10045885	4.45"	4.65"
FL Steer	10045883	5.2"	5.4"
R-Drive	10045887	5.6"	5.85"
TN-Trailer	10045888	5.6"	5.85"
TP-Trailer	10045889	5.6"	5.85"

- 5. When installing the ConMet seal, tap the adapter plate of the installation tool around the outer edge to position the seal. Drive the wheel seal into place (see figure 56). Once the tool bottoms out, the seal is installed correctly.





FIGURE 56

- 6. Check to be certain the seal is not cocked and that the seal inner diameter and the inner bearing turn freely.

CAUTION

Failure to lubricate the inner diameter of the seal may result in premature seal failure.


- 7. Lubricate the inner diameter of the seal with a light film of the same lubricant as will be used in the hub.
- 8. Turn the hub over, and place it seal end down. For all drive and trailer hubs, install a bearing spacer. If the spacer has a tapered end, it should face towards the outboard end of the hub (see figure 57).



Installing the Spacer
FIGURE 57

5. PRESET WHEEL HUBS – REASSEMBLY

- Lubricate the outer bearing cone with the same lubricant as will be used in the hub and install it into the hub assembly (see figure 58).



Installing the Outer Bearing Cone
FIGURE 58

5. PRESET WHEEL HUBS – REINSTALLATION

INSTALLING THE PreSet WHEEL HUB ASSEMBLY

Spindle Preparation


- Clean the spindle** to remove any lubricant, corrosion prevention coating, foreign material, or surface rust that may be present. Be sure to clean the full length of the seal journal.
- Lubricate the bearing journals on the spindle**, or the inside diameter of the bearing cones with Grade 2 grease or the lubricant that will be used in the wheel end. Do not coat the seal journal on the spindle.
- Lubricate the inside diameter of the seal** with the same lubricant that will be used in the wheel end.

CAUTION

Failure to apply lubricant to the bearing journals will result in fretting corrosion, which may result in difficulty removing the bearing. Never support the hub on the spindle with just the inner bearing and seal. This can damage the seal and cause premature failure, i.e., by cocking the seal in the bore.

Mounting the Hub

- Mount the hub assembly onto the axle spindle with a smooth, firm motion while holding the outer bearing in place. Use care to maintain alignment between the bearing cones, spacer, and spindle and to avoid seal damage (see figure 59).



Mounting the Assembly
FIGURE 59

CAUTION

Once the hub is on the spindle, do not remove the outer bearing. Removing the outer bearing may cause the seal to become misaligned, resulting in premature seal failure.

Spindle Nut Torque

- One-Piece Spindle Nut System (Pro-Torq® and Axilok®)**
If a one-piece spindle nut system is being used, torque the nut to a minimum of 300 ft-lbs. **Do not back off the spindle nut. Advance as necessary to engage any locking device.**
 - Double Nut or Jam Nut System**

If a double nut or jam nut system is being used, torque the inner nut to 300 ft-lbs. **Do not back off the spindle nut.** Advance the inner nut as necessary to install the locking ring. Install the outer nut with 200 ft-lbs of torque. **Be sure to engage any locking device.**

NOTE

ConMet does not recommend a one-piece "castellated" type nut system for use with PreSet hubs.

NOTE

The hubcap bolt holes must be free of debris, such as silicone gasket sealer to ensure the bolts will tighten properly to avoid leaks. Silicone trapped in the hubcap screw holes can create hydraulic pressures during hubcap screw installation, leading to premature hub failure through the hubcap holes. The vent should also be clean and free of debris. Remove any burrs or sharp edges. Always use new gaskets.

- Install the hub cap or drive axle with a new gasket.** Torque the hub cap bolts in a star pattern to 12 to 18 ft-lbs. Torque the drive axle bolts or nuts per the drive axle manufacturer's recommendation.

NOTE

Use SAE Grade 5 bolts or stronger. Do not use star washers. Use only flat washers or split washers.

5. PRESET WHEEL HUBS – SERVICE PARTS

Axle Designations

Designation	Typical Axle Rating (lbs)	Comments
Steer Axle		
FC Steer	8,000	Medium duty
FF Steer	12,000-14,700	Standard linehaul axle. Comes in two spindle variations. 1. Flat locking feature with 12 threads/inch. 2. Keyway locking feature with 18 threads/inch.
FL Steer	20,000	Vocational applications
Drive Axle		
L-Drive	19,000	Medium duty
R-Drive	20,000-23,000	Standard linehaul axle
Trailer Axle		
TN Trailer	22,500	Tapered spindle
TP Trailer	25,000	Parallel spindle or "Propar"

NOTE: These axle ratings are to be used as a reference only. Refer to the vehicle's door plate for your specific application.

PreSet Service Kits and Components

PreSet Hubs	Rebuild Kit	Seal and Spacer Kit	Magnetic Fill Plug
FC Steer	10037697	10084179	N/A
FF Flat	10081727	10081518	N/A
FF Keyway	10081727	10081518	N/A
FL Steer	10081728	10081519	N/A
F-Drive	10081076	N/A	N/A
L-Drive	10037961	10084178	10033073
R-Drive	10081729	10081520	10033073
TN (Tapered)	10081730	10081521	10033073
TP (Straight)	10081731	10081522	10033073

Rebuild kit includes seal, bearing spacer, inner cup and cone, outer cup and cone.
Seal and spacer kit includes seal and bearing spacer.

NOTE

Bearing cups and cones must be replaced as a set.

NOTE

When bearings are replaced in any PreSet hub, it is recommended that the bearing spacer be replaced as well.

ConMet Seals

Position	Spindle Type	Aftermarket Part Number
Steer	FF Spindle	10045885
	FL Spindle	10045883
Drive	R Spindle	10045887
Trailer	TP Spindle	10045889
	TN Spindle	10045888

5. PRESET WHEEL HUBS – SERVICE PARTS

ConMet Seal Installation Tools

Axle Designation	Installation Tool Part Number	Min. Dia.*	Max. Dia.*
FF Steer	10084010	4.45"	4.65"
FL Steer	10084011	5.2"	5.4"
R-Drive	10084012	5.6"	5.85"
TN Trailer	10084013		
TP Trailer	10084013		

*Required flat plate dimensions if you are not using a ConMet installation tool (minimum of 3/8", 9.5 mm thick).

Approved PreSet Aftermarket Bearings

Description	ConMet Number	Bearing Set Number
FC Steer Axle		
Inner Cup & Cone	10037695	Not available in sets
Outer Cup & Cone	10037696	
FF Steer Axle		
Inner Cup & Cone	10041905	Set 427
Outer Cup & Cone	10041906	Set 428
FL Steer Axle		
Inner Cup & Cone	10041925	Set 445
Outer Cup & Cone	10041926	Set 446
L-Drive Axle		
Inner Cup & Cone	10037959	Not available in sets
Outer Cup & Cone	10037960	
R-Drive Axle		
Inner Cup & Cone	10041915	Set 429
Outer Cup & Cone	10041916	Set 430
TN Trailer Axle		
Inner Cup & Cone	10041935	Set 431
Outer Cup & Cone	10041905	Set 427
TP Trailer Axle		
Inner Cup & Cone	10041945	Set 432
Outer Cup & Cone	10041945	Set 432

5. PRESET WHEEL HUBS – SERVICE PARTS

ABS Rings for ConMet Hubs (for reference only)

Axle	Material	Type of Brake	Hub Casting Number	ABS Ring Part Number
FC Steer	Iron	Drum	10016569	10016586
FF Steer	Aluminum	Disc	10016331	10009780
			10018723	10009780
			10020207	10009780
		Drum	101945	10009780
			103110	10009780
			104112	10009780
			10000776	10009780
	Iron	Disc	10011945	10009780
		Drum	10019965	10023558
			10005604	10009780
FL	Aluminum	Drum	10012265	10019840
	Iron	Disc	10005561	107912
L-Drive (190)	Iron	Disc	10020602	10023559
		Drum	10020627	10023757
R-Drive	Aluminum	Disc	10016328	103705
		Drum	10001280	103705
	Iron	Drum	10001387	103705
			10018310	103705
			10018311	103705
TN	Aluminum	Drum	102035	105459
TP	Aluminum	Disc	10016620	10019896
		Drum	10001216	105459
	Iron	Drum	10025633	10023829

NOTE

If an ABS ring is not listed for a particular hub, contact ConMet Customer Service at 800-547-9473.

Approved Trailer Hub Caps


Axle Designation	Type of Lubricant	PreSet Hub Cap Part Number
TN Trailer	Semi-Fluid Grease	10018622
TP Trailer	Semi-Fluid Grease	10018621
TN Trailer	Oil	106819
TP Trailer	Oil	106870

6. PRESET PLUS WHEEL HUBS – RECOMMENDED SERVICE

PreSet Plus Hub Assemblies

ConMet PreSet Plus hub assemblies feature the same PreSet technology and include the same precision-machined hubs, premium seals and specially toleranced roller bearings. However, PreSet Plus hubs incorporate the following:

- An integrated spindle nut that eases installation and disassembly and protects components during wheel end service
- An optimized spacer
- Standard magnetic fill plug



PreSet Plus Hub and Components
FIGURE 60

When inspections indicate that service is necessary on a PreSet Plus Hub, follow the recommended service, inspection, reassembly and reinstallation instructions found in the following section.

In order to ensure optimum wheel hub performance, ConMet recommends that only approved PreSet Plus service parts be used to replace all critical components of the system. Refer to the back of this section for a listing of approved parts.

HUB REMOVAL AND DISASSEMBLY

WARNING

Vehicles on jacks can fall, causing serious personal injury or property damage. Never work under a vehicle supported by a jack without supporting the vehicle with stands and blocking the wheels. Wear safe eye protection.

1. Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving.
2. Raise the axle until the tires are off the floor.
3. Place safety stands under the trailer frame or under each axle spring seat (see figure 61).




FIGURE 61

4. Remove the tire and wheel assembly using procedures specified by the wheel manufacturer (see figure 62).




FIGURE 62

WARNING

Sudden release of compressed air can cause serious personal injury and damage to components. Before you service a spring chamber, carefully follow the manufacturer's instructions to compress and lock the spring to completely release the brake. Verify that no air pressure remains in the service chamber before you proceed.

5. If the axle is equipped with spring brake chambers, carefully compress and lock the springs so that they cannot actuate (see figure 63).





FIGURE 63

6. For drum brakes, remove the brake drum. Support the drum during the removal process to prevent damage to the components. For disc brakes, remove caliper per manufacturers' recommended procedure.

NOTE

If the hub to be disassembled is a drive hub, remove the drive axle shaft, and capture the oil (see figure 64).



Removing the Drive Axle Shaft
FIGURE 64

6. PreSet Plus Wheel Hubs – Recommended Service

7. Place a container under the hubcap, or drive axle shaft for a drive hub, to receive the draining oil, then remove the hubcap or drive axle shaft. Do not reuse the oil. Correctly dispose of the lubricant.
8. Remove the red locking ring. Use caution not to damage the locking ring. Do not remove the spiral snap ring that holds the spindle nut in the hub.

WARNING

Do not loosen the axle spindle nuts by either striking them directly with a hammer, or striking a drift or chisel placed against them. Damage to the parts will occur causing possible loss of axle wheel-end components and serious personal injury.

9. Use a breaker bar to loosen the spindle nut. PreSet Plus spindle nut installation torque is 300 ft-lbs for steer hubs and 500 ft-lbs for drive and trailer hubs.

NOTE

Use only 6-point forged sockets for installation and removal of PreSet Plus spindle nuts.


Socket Sizes for PreSet Plus Spindle Nuts

	FF Flat	FF Keyway	FL
Socket Size (6 Point)	2"	2"	2.75"

	R	TN	TP
Socket Size (6 Point)	3.75"	3.125"	4"

10. After the spindle nut is initially loosened with a breaker bar, loosen the spindle nut to remove the hub from the spindle. The internal snap ring will act as a hub puller and will aid in removal of the hub from the spindle. Do not exceed 50 ft-lbs of torque when removing

the hub from the spindle. If the hub will not come off of the spindle without exceeding this torque value, remove the spiral snap ring (see figure 65) and the spindle nut assembly and use a conventional hub puller to remove the hub from the spindle.



Spiral Snap Ring Removal
FIGURE 65

11. Slide the hub off the spindle. Remove and save the outer bearing cone. Be careful when you remove the hub that you do not damage the outer bearing by dropping it on the floor.

- If the hub is difficult to remove because the seal is stuck on the spindle, use a mechanical puller to remove the hub (see figure 66).
- If part of the seal remains on the spindle, carefully remove the part of the seal that remains on the spindle.

NOTE

This can be done by striking the remaining portion of the seal with the round end of a ball-peen hammer. Use caution not to damage the seal journal on the spindle.





FIGURE 66

12. Place the hub on its outboard end and remove the seal. Retain the seal if it needs to be returned for warranty consideration.
13. Remove the inner bearing cone and spacer (see figure 67).



Hub Disassembly
FIGURE 67

6. PreSet Plus Wheel Hubs – Recommended Service

COMPONENT INSPECTION AND REPLACEMENT
HAZARD ALERT MESSAGES

Read and observe all hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.

WARNING

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

Observe all warnings and cautions provided by the press manufacturer to avoid damage to components and serious personal injury.

Do not hit steel parts with a steel hammer. Pieces of a part can break off. Serious personal injury and damage to components can result. Use a brass or synthetic mallet for assembly and disassembly procedures.

Solvent cleaners can be flammable, poisonous and cause burns. Examples of solvent cleaners are carbon tetrachloride, and emulsion-type and petroleum-base cleaners. Read the manufacturer's instructions before using a solvent cleaner, then carefully follow the instructions. Also follow the procedures below.

- Wear safe eye protection.
- Wear clothing that protects your skin.
- Work in a well-ventilated area.
- Do not use gasoline or solvents that contain gasoline. Gasoline can explode.
- You must use hot solution tanks or alkaline solutions correctly. Read the manufacturer's instructions before using hot solution tanks and alkaline solutions. Then carefully follow the instructions.

CAUTION

Do not use hot solution tanks or water and alkaline solutions to clean ground or polished parts. Damage to parts can result.

CLEAN AND DRY COMPONENTS

Worn or Damaged Components

WARNING

Do not repair or recondition wheel-end components. Replace damaged, worn or out-of-specification components. Do not mill or machine any components. Using repaired, reconditioned, damaged or worn components can cause wheel end failure, which can result in serious injury and property damage.

Hub and Component Cleaning

1. Use a clean filtered solvent to clean the hub and all wheel end components.
2. Do NOT clean ground or polished parts in a hot solution tank or with water, steam or alkaline solutions. These solutions will cause corrosion of the parts.
3. Clean and inspect the wheel bearing cups and cones, race, spindle bearing and seal journals on the spindle and hub. Bearings should be cleaned with clean filtered solvent and dried with either compressed air or a lint-free rag.

CAUTION

If compressed air is used, do not spin dry the bearings. The rollers may score due to lack of lubricant and rollers could come off which can result in serious injury. Ensure that the air line is moisture free.

4. Clean and inspect the spindle. Be sure to clean the full length of the seal journal on the spindle.
5. Parts must be dried immediately after cleaning. Dry parts with clean paper towels or rags, or compressed air. Do not dry bearings by spinning with compressed air.

6. Apply a light oil to cleaned and dried parts that are not damaged and are to be immediately assembled. Use only the type of oil used by the manufacturer. Do NOT apply oil to the brake linings or the brake drums.
7. If the parts are to be stored, apply a good corrosion preventative to all surfaces. Do NOT apply the material to the brake linings or the brake drums. Store the parts inside special paper or other material that prevents corrosion.

INSPECTING BEARING CUPS AND CONES AND BEARING SPACER

NOTE

PreSet and PreSet Plus hubs use a precision-machined spacer in conjunction with specially toleranced bearings to control wheel end play. ConMet recommends installing a new PreSet/PreSet Plus service kit when inspection indicates that component replacement is necessary. PreSet/PreSet Plus service kits are available from a parts dealer or distributor.

CAUTION

If you choose to reuse existing bearings at this service, they must be inspected in accordance with the bearing manufacturers recommended guidelines.


CAUTION

If this inspection indicates that existing bearing component(s) must be replaced, bearing cups and cones must be replaced as a set. Whenever new bearings are installed, replacement of the bearing spacer is also recommended.

6. PRESet PLUS WHEEL HUBS – RECOMMENDED SERVICE

- After components have been properly cleaned, visually inspect the cups, cones and spacer for any wear or damage. Reference materials for proper bearing inspection procedures are available from the bearing manufacturers.

Bearing spacers should be visually inspected for signs of wear or damage. Carefully inspect the machined ends of the bearing spacer. Wear to the bearing spacer can appear as a sharp ring of standing metal at either edge of the machined surfaces (see figure 68). Replace the spacer if it has visible wear evidenced by a raised edge on the machined end.




Bearing Spacer Wear
FIGURE 68

- If removal or replacement is required, follow the steps outlined below.

REMOVING CUPS IN ALUMINUM HUBS

- If the bearing cup must be removed from an aluminum hub, remove it by welding a large bead around the bearing surface of the steel cup, letting the assembly cool, and removing the bearing cup (see figure 69).



Welding Bead
FIGURE 69

- Inspect the bearing cup bore for evidence of cup rotation or spun cups.
 - If cup rotation exists, replace the hub.


REMOVING CUPS IN IRON HUBS

- On an iron hub, remove the bearing cup using a large hammer and a mild steel bar or a hydraulic press. Take precaution to avoid damaging the bearing cup bore and shoulder.
- Inspect the bearing cup bore for evidence of cup rotation or spun cups.
 - If cup rotation exists, replace the hub.

INSTALLING A NEW CUP IN ALUMINUM HUBS

To install a new cup in an aluminum hub, it is recommended that the hub be heated in boiling water (212°F) or in an oven at a temperature not to exceed 300°F. Cooling the cup in a

freezer to 32°F or below will further ease the installation.




Do not overheat the hub as it may degrade the heat-treated strength of the hub. Do not heat the hub with a torch or open flame.

Remove the aluminum hub from the oven or water and carefully drop in the new bearing cup being certain it is fully seated. If the cup is loose, allow a few seconds for it to heat up and secure itself before moving the hub. Use a 0.001" to 0.002" feeler gauge to ensure the cup is fully seated against the shoulder of the bearing bore.

INSTALLING A NEW CUP IN IRON HUBS

Iron hubs do not need to be heated for bearing cup installation. Press the bearing cup into the hub, being certain that it is fully seated (see figure 70). Use a 0.001" to 0.002" feeler gauge to ensure the cup is fully seated against the shoulder of the bearing bore.




Bearing Cup Pressed into Hub
FIGURE 70

WHEEL STUDS

Replace all wheel studs that have damaged or distorted threads, are broken or bent, or are badly corroded. Also, replace both studs adjacent to the damaged stud. If two or more studs have damage, replace all the studs in the hub. Broken studs are usually an indication of excessive or inadequate wheel nut torque.


6. PRESet PLUS WHEEL HUBS – RECOMMENDED SERVICE

STUD REMOVAL



Observe all warnings and cautions for press operation provided by the press manufacturer to avoid serious personal injury and damage to components.

- Place the clean hub in a shop press with the hub supported evenly around and adjacent to the stud being removed.




Failure to adequately support the hub can result in physical injury and/or damage to the hub.

Some hubs are configured so it is impractical to have supports to prevent the hub from tipping when force is applied to the stud. In this case, support the hub on wood blocks on the floor and use a heavy hammer to drive the studs out with several sharp blows. Be careful to avoid damaging the hub and components, particularly the seal bore and the ABS tone ring.


- Press the stud out of the hub.

STUD REPLACEMENT



On the ball seat wheel mounting system, always use left-handed threaded studs, which are gold in color and have an "L" stamped on the end, in the hub on the driver's side of the equipment, and use right-handed threaded studs, which are silver in color and have an "R" stamped on the end, in the hub on the passenger's side of the equipment. The ConMet part number is located on the head of the stud. The same part number must be used for replacement unless changing the drum or wheel type.


- To install a new stud, support the hub evenly around and adjacent to the stud being installed.
- Press the new stud all the way into the hub. Be sure the stud is fully seated and that the stud head is not embedded into the hub.



Excessive force can cause the stud head to be embedded into the hub, which can create a crack in the hub, resulting in serious injury and property damage. If a stud head is embedded in a hub, replace the hub.

HUB, DRUM AND WHEEL INSPECTION

- Inspect the drum pilots, wheel pilots, and mounting face on the hub for damage. A damaged drum pilot is usually caused by improper drum mounting. A damaged wheel pilot could be the result of inadequate wheel nut torque, allowing the wheels to slip in service. Also, inspect other surfaces of the hub for signs of cracks or damage.
- Inspect the wheels and brake drum for damage.



Do not repair or recondition wheel-end components. Replace damaged, worn or out-of-specification components. Do not mill or machine any components. Using repaired, reconditioned, damaged or worn components can cause wheel end failure, which can result in serious injury and property damage.

ABS TONE RING INSPECTION (AS APPLICABLE)

The Anti-Lock Braking System (ABS) signals acts like any signal generator where the magnet passes a coil and generates a current. On hubs, the toothed ring passes a sensor and generates a signal that is sent to the ABS computer. There are three types of ABS rings used on ConMet hubs — machined, stamped steel and bolt on (see figure 71).





FIGURE 71

If the tone ring is damaged (for example, if it is dropped, bent, chipped or dinged), it must be replaced. For a list of replacement ABS rings, refer to the Service Parts List in the back of this section.

REMOVAL AND INSTALLATION OF MACHINED ABS TONE RING

For a machined metal ring, remove using a chisel, making sure not to damage the hub (see figure 72). Reinstall by heating the ring to 350°F in an oven and installing it on the hub.




Machined ABS Ring
FIGURE 72


6. PRESET PLUS WHEEL HUBS – RECOMMENDED SERVICE

REMOVAL AND INSTALLATION OF STAMPED STEEL ABS TONE RING

1. The steer axle tone ring can be removed by gripping the ring with a pair of locking pliers and tapping the pliers upward with a rubber mallet. Work around the ring to keep the ring from cocking (see figure 73). Drive axle and trailer tone rings can be removed by gripping the ring with a pair of locking pliers and prying against the head of a wheel stud to lift the ring off the hub. Work around the ring to prevent cocking (see figure 74).



Stamped Steel ABS Ring
FIGURE 73



Stamped Steel ABS Ring
FIGURE 74

2. Thoroughly clean and degrease the ABS ring seat on the hub with a nonflammable solvent.


CAUTION

Replace the hub if the ABS ring seat is damaged.
The ABS ring must be fully seated with a maximum of 0.008" axial runout to ensure the ABS system functions properly.

NOTE


For steer hubs, be certain the inside diameter flange is facing up.

3. Place the hub in a press and place the ABS ring on the hub ring seat.
4. Using ConMet ring installation tool (part number 107119), center the tool over the ABS ring. Each type of ring fits a corresponding diameter on the tool (see figure 75).



Installing the ABS Tone Ring
FIGURE 75

5. Press the ring on the hub. If a press is not available, drive the ring on with a hammer or mallet until the ring seats on the hub (see figure 76). A swift initial blow with an 8-lb. hammer may be necessary to start the ring onto the hub.



Using a Hammer to Install the Ring
FIGURE 76

6. Inspect the ring to ensure proper seating. If the ring is not completely seated, continue to drive the ring with the ring installation tool until it is completely seated.

REMOVAL AND INSTALLATION OF BOLT ON ABS TONE RINGS (For Disc Brakes)

1. Remove and discard the fasteners holding the ABS tone ring on the hub.
2. Thoroughly clean and degrease the ABS ring seat on the hub with a non-flammable solvent.
3. Install the new ABS ring using the new fasteners included with the ring. Torque the fasteners to the torque specifications below.

Thread Size	Torque
#8-32	18-22 in-lbs
1/4"-20	155-165 in-lbs

6. PRESET PLUS WHEEL HUBS – REASSEMBLY

PreSet Plus WHEEL HUBS

CAUTION


When using an oil bath system, do not pack the bearing with grease. Grease will prevent the proper circulation of axle lubricant and can cause premature wheel seal and bearing failure.

1. Place the hub, seal end up, on a clean work bench surface.

NOTE


If you are working on a drive or trailer hub, go to step 3. If you are working on a steer hub, proceed as follows.

2. For steer hubs, install the tubular bearing spacer with the tapered end down (see figure 77).



Bearing Cone Assembly
FIGURE 77

3. Lubricate the inner bearing cone with the same lubricant as will be used in the hub and install it into the inner bearing cup (see figure 78).



Bearing Cone Assembly
FIGURE 78

NOTE

The seal must be replaced every time the hub is removed from the spindle. Do not apply any gasket sealant to the seal outer or inner diameter. Always use the seal installation tool specified by the seal manufacturer. Using an improper tool can distort or damage the seal and cause premature seal failure.

4. Position the seal into the hub bore. Use a ConMet seal installation tool or flat plate and a small mallet to install the seal.

NOTE

ConMet seals require the proper tool for installation. Refer to the table below for a ConMet seal installation tool or flat plate dimensions. For other seals, refer to the specific manufacturers' instructions.

ConMet Seal Installation Tools

Axle Type	Part Number
FF Steer	10084010
FL Steer	10084011
R-Drive	10084012
TN Trailer	10084013
TP Trailer	10084013

Flat Plate Dimensions

Application	Seal Part Number	Min. Dia.	Max. Dia.
FF Steer	10045885	4.45"	4.65"
FL Steer	10045883	5.2"	5.4"
R-Drive	10045887	5.6"	5.85"
TN-Trailer	10045888	5.6"	5.85"
TP-Trailer	10045889	5.6"	5.85"

5. When installing the ConMet seal, tap the adapter plate of the installation tool around the outer edge to position the seal. Drive the wheel seal into place (see figure 79). Once the tool bottoms out, the seal is installed correctly.





FIGURE 79

6. Check to be certain the seal is not cocked and that the seal inner diameter and the inner bearing turn freely.

CAUTION

Failure to lubricate the inner diameter of the seal may result in premature seal failure.


7. Lubricate the inner diameter of the seal with a light film of the same lubricant as will be used in the hub.
8. Turn the hub over, and place it seal end down. For all drive and trailer hubs, install a bearing spacer. If the spacer has a tapered end, it should face towards the outboard end of the hub (see figure 80).



Installing the Spacer
FIGURE 80

9. Lubricate the outer bearing cone with the same lubricant as will be used in the hub and install it into the hub assembly (see figure 81).


6. PRESet PLUS WHEEL HUBS – REASSEMBLY



Installing the Outer Bearing Cone
FIGURE 81


Spindle Nut and Spiral Snap Ring
Reassembly

1. Seat the flat washer into the back of the spindle nut (see figure 82).




Seating Flat Washer into Spindle Nut
FIGURE 82

2. Position the spindle nut and washer against the outer bearing (see figure 83).




Positioning Nut and Washer Against Bearing
FIGURE 83

3. Install the spiral snap ring into the snap ring groove in the hub. Make sure that the snap ring is fully seated into the groove in the hub (see figures 84 and 85).



Installing Spiral Snap Ring
FIGURE 84



Fully Seating Spiral Snap Ring in Groove of Hub
FIGURE 85

6. PRESet PLUS WHEEL HUBS – REINSTALLATION

INSTALLING THE PreSet
Plus WHEEL HUB
ASSEMBLY



WARNING

Failure to fill the hub with the correct amount of lubricant can cause premature failure of the PreSet Plus hub assembly, which, if not avoided, could result in death or serious injury.

NOTE

Use the proper hubcap for the type of lubricant intended to be used.

1. **Clean the spindle** to remove any lubricant, corrosion prevention coating, foreign material, or surface rust that may be present.
2. **Lubricate the bearing journals on the spindle**, or the inside diameter of the bearing cones with Grade 2 grease or the lubricant that will be used in the wheel end. Do not coat the seal journal on the spindle.
3. **Lubricate the inside diameter of the seal** with the same lubricant that will be used in the wheel end.
4. If present, remove the red locking snap ring from the spindle nut. Verify that the bearing spacer is in proper alignment. Align the key or flat on the washer with the keyway or flat on the spindle as the hub is placed onto the spindle. **Use a smooth firm motion and place the hub onto the spindle.** When the threads on the nut engage the threads on the spindle, rotate the nut in a clockwise direction to fully engage the threads.
5. Torque the spindle nut to the following torque values:

Steer Hub – Torque the spindle nut to 300 ft-lbs while rotating the hub. **DO NOT BACK OFF THE SPINDLE NUT.**

Drive Hub or Trailer Hub – Torque the spindle nut to 500 ft-lbs while rotating the hub. **DO NOT BACK OFF THE SPINDLE NUT.**

Socket Sizes for PreSet Plus Spindle Nuts

	FF Flat	FF Keyway	FL
Socket Size (6 Point)	2"	2"	2.75"

	R	TN	TP
Socket Size (6 Point)	3.75"	3.125"	4"

6. **Visually examine the three holes in the face of the spindle nut. One of the holes will line up with the holes in the inner washer. Install the tab of the red locking snap ring through the hole in the nut and washer that are aligned. Spread the locking ring, push it over the spindle nut and in to the machined grooves in the spindle nut.** Use caution not to bend the locking ring permanently. If the locking ring is damaged or bent, replace it with a new one.
7. **Install the hub cap or drive axle with a new gasket.** Torque the hub cap bolts in a star pattern to 12 to 18 ft-lbs. Torque the drive axle bolts or nuts per the drive axle manufacturer's recommendation.

6. PRESET PLUS WHEEL HUBS – SERVICE PARTS

Axle Designations

Designation	Typical Axle Rating (lbs)	Comments
Steer Axle		
FC Steer	8,000	Medium duty
FF Steer	12,000-14,700	Standard linehaul axle. Comes in two spindle variations. 1. Flat locking feature with 12 threads/inch. 2. Keyway locking feature with 18 threads/inch.
FL Steer	20,000	Vocational applications
Drive Axle		
L-Drive	19,000	Medium duty
R-Drive	20,000-23,000	Standard linehaul axle
Trailer Axle		
TN Trailer	22,500	Tapered spindle
TP Trailer	25,000	Parallel spindle or "Propar"

NOTE: These axle ratings are to be used as a reference only. Refer to the vehicle's door plate for your specific application.

PreSet Plus Service Kits and Components

PreSet Plus Hubs	Rebuild Kit	Seal and Spacer Kit	Magnetic Fill Plug	Nut Assembly Kit*	Red Locking Snap Ring*
FF Flat	10081727	10081518	N/A	10036548	10026174
FF Keyway	10081727	10081518	N/A	10036549	10026174
FL	10081728	10081519	N/A	10036550	10031172
R-Drive	10081729	10081520	10033073	10036551	10026147
TN	10081730	10081521	10033073	10036552	10031029
TP	10081731	10081522	10033073	10036553	10030837

Rebuild kit includes seal, bearing spacer, inner cup and cone, outer cup and cone. Seal and spacer kit includes seal and bearing spacer. Nut assembly kit includes integrated spindle nut, locking washer, red locking snap ring and spiral nut retaining ring.

*Not available for PreSet hub assemblies.

ConMet Seals

Position	Spindle Type	Aftermarket Part Number
Steer	FF Spindle	10045885
	FL Spindle	10045883
Drive	R Spindle	10045887
Trailer	TP Spindle	10045889
	TN Spindle	10045888

6. PRESET PLUS WHEEL HUBS – SERVICE PARTS

ConMet Seal Installation Tools

Axle Designation	Installation Tool Part Number	Min. Dia.*	Max. Dia.*
FF Steer	10084010	4.45"	4.65"
FL Steer	10084011	5.2"	5.4"
R-Drive	10084012	5.6"	5.85"
TN Trailer	10084013		
TP Trailer	10084013		

*Required flat plate dimensions if you are not using a ConMet installation tool (minimum of 3/8", 9.5 mm thick).

Approved PreSet Plus Aftermarket Bearings

Description	ConMet Number	Bearing Set Number
FC Steer Axle		
Inner Cup & Cone	10037695	Not available in sets
Outer Cup & Cone	10037696	
FF Steer Axle		
Inner Cup & Cone	10041905	Set 427
Outer Cup & Cone	10041906	Set 428
FL Steer Axle		
Inner Cup & Cone	10041925	Set 445
Outer Cup & Cone	10041926	Set 446
L-Drive Axle		
Inner Cup & Cone	10037959	Not available in sets
Outer Cup & Cone	10037960	
R-Drive Axle		
Inner Cup & Cone	10041915	Set 429
Outer Cup & Cone	10041916	Set 430
TN Trailer Axle		
Inner Cup & Cone	10041935	Set 431
Outer Cup & Cone	10041905	Set 427
TP Trailer Axle		
Inner Cup & Cone	10041945	Set 432
Outer Cup & Cone	10041945	Set 432

6. PRESET PLUS WHEEL HUBS – SERVICE PARTS

ABS Rings for ConMet Hubs (for reference only)

Axle	Material	Type of Brake	Hub Casting Number	ABS Ring Part Number
FC Steer	Iron	Drum	10016569	10016586
FF Steer	Aluminum	Disc	10016331	10009780
			10018723	10009780
			10020207	10009780
		Drum	101945	10009780
			103110	10009780
			104112	10009780
			10000776	10009780
	Iron	Disc	10011945	10009780
			10019965	10023558
		Drum	10005604	10009780
FL	Aluminum	Drum	10012265	10019840
	Iron	Disc	10005561	107912
L-Drive (190)	Iron	Disc	10020602	10023559
		Drum	10020627	10023757
R-Drive	Aluminum	Disc	10016328	103705
		Drum	10001280	103705
	Iron	Drum	10001387	103705
			10018310	103705
			10018311	103705
TN	Aluminum	Drum	102035	105459
TP	Aluminum	Disc	10016620	10019896
		Drum	10001216	105459
	Iron	Drum	10025633	10023829

NOTE

If an ABS ring is not listed for a particular hub, contact ConMet Customer Service at 800-547-9473.

Approved Trailer Hub Caps

Axle Designation	Type of Lubricant	PreSet Plus Hub Cap Part Number
TN Trailer	Semi-Fluid Grease	10036694
TP Trailer	Semi-Fluid Grease	10036693
TN Trailer	Oil	10036692
TP Trailer	Oil	10036691

7. LUBRICATION

DRIVE HUB LUBRICATION

Drive hubs can be lubricated by installing one quart of oil through the fill plug in the barrel of the hub.



The proper installation torque for the fill plug is 20-25 ft-lbs.

If no fill plug is present, the drive hub can be lubricated by lifting the opposite side of the axle 8" to allow the lubricant to run down the axle housing and into the hub assembly. Elevate the axle for two minutes to allow the lubricant time to fill the hub. Repeat the process for the opposite side of the vehicle. The rear axle carrier should be filled to the proper level to ensure adequate lubricant is available to fill the entire hub. Refill the carrier to the proper level after this procedure is completed.


STEER AND TRAILER HUBS WITH OIL LUBRICANT

NOTE

Only use oil approved by the seal manufacturer (see approved list from the seal manufacturer or on www.conmet.com).


Some hubs are provided with a fill hole, located in the barrel and between the bearings for adding lubricant.

1. Fill the hub through the hubcap or the fill hole with oil. It may be necessary to add lubricant more than once to adequately fill the hub (see figure 86).



Filling the Hub with Oil
FIGURE 86

2. Be certain the hubcap is properly filled to the "oil level" mark on the face of the cap (see figure 87). Allow the initial fill amount to settle for 10 minutes. Repeat the fill procedure until the oil is at the fill line on the hubcap.



Fill to "Oil Level Line"
FIGURE 87

3. Be sure to put the fill hole plug back into the hubcap and that the vent is working properly.

TRAILER HUBS WITH SEMI-FLUID GREASE LUBRICANT




Failure to fill and maintain the hub with the correct amount of semi-fluid grease may cause premature failure of the wheel hub system, bearing failure and possible loss of the wheel.

1. Remove the fill hole plug.
2. Loosen the hubcap bolts to allow air to escape while the hub is filling.

3. Fill the hub with the OEM recommended amount of room temperature (60°F minimum) semi-fluid grease through the fill hole in the hub (see figure 88).

For proper fill levels using semi-fluid grease, see the chart on the next page.



Filling Hub with Semi-Fluid Grease
FIGURE 88

4. Retorque the hubcap bolts to 12-18 ft-lbs in a star pattern.
5. Reinstall and tighten the fill plug to 20-25 ft-lbs.

7. LUBRICATION (CONTINUED)

Recommended Fill Volumes for Semi-Fluid Grease

HUB TYPE	MATERIAL	BRAKE TYPE	NO. OF STUDS	CASTING NUMBERS*	PreSet VOLUME** (FL.OZ.)	Non PreSet VOLUME (FL.OZ.)
TN	Aluminum	Drum	10	100164	22.6	25.6
			8	101143	22.6	25.6
			10	102035	18.8	21.8
			8	102610	18.8	21.8
		Disc	10	10001896	18.8	21.8
			10	10017979	18.8	21.8
	Iron	Drum	10	10003636	27.0	30.0
			10	10020219	27.0	30.0
			10	10023666	23.0	26.0
			10	10033293	23.0	26.0
			10	10083937	23.0	26.0
		Disc	10	10083541	25.0	28.0
			10	10083557	25.0	28.0
TP	Aluminum	Drum	10	100510	41.4	41.4
			8	101259	41.4	41.4
			10	10001216	41.4	41.4
			10	10033028	41.4	41.4
		Disc	10	10016225	41.4	41.4
			10	10016620	46.9	46.9
	Iron	Drum	10	10003654	55.0	55.0
			10	10025633	35.0	35.0
			10	10033241	35.0	35.0
			10	10083939	35.0	35.0
		Disc	10	10009758	55.0	55.0
			10	10083549	55.0	55.0
			10	10083565	55.0	55.0

*Hub casting numbers can be found cast onto the flange of the hub. For part numbers that don't appear in the chart, contact ConMet customer service at 800-547-9473 or go to conmet.com.
**These fill volumes were established with ConMet hubcaps and are to be used as reference only.

8. BRAKE AND WHEEL INSTALLATION

Caliper Installation

Reinstall and adjust the brake pads and brake caliper according to the brake manufacturer's recommended instructions.

Wheel Installation

- 1. Reinstall the wheels and torque the wheel bolts in a star pattern to 450-500 ft-lbs. The last nut rotation must be with a torque-controlled device.
- 2. After the first 50 to 100 miles, retorque the wheel nuts to 450-500 ft-lbs in a star pattern. The last nut rotation must be with a torque-controlled device.

Hub Pilot Wheel Mounting System

CAUTION


The brake drum must be fully seated on the drum pilot and against the hub face during and after installation of the wheel(s).

NOTE


If your shop practice requires the use of lubricant or anticorrosion material to the threads and/or the drum pilot area, avoid getting lubricant on the flat mating surfaces of the hub, drum, and wheels.

WARNING

Always snug the top nut first to fully seat the brake drum on the drum pilot and against the hub face. See the adjacent diagram for bolt tightening sequence, and tighten in order from 1 through 8 or 10, depending on the bolt pattern (see figure 89 and figure 90).



10 Stud Tightening Sequence
FIGURE 89



8 Stud Tightening Sequence
FIGURE 90


- 1. Clean all mating surfaces on the hub, drum and nuts. Remove loose paint, scale, and any material building around the pilots of the drum, hub, and wheels. Be sure paint is fully cured on recently refurbished wheels.

CAUTION

Care should be taken to avoid damaging the hub or other components.

NOTE

If you plan to replace the brake drum (i.e., cast in place of CentriFuse®) or wheels (i.e., aluminum in place of steel), measure stud stand-out (see figure 91). In hub piloted mounting systems, the studs must be long enough for the threads to be exposed beyond the installed wheel nut. In the ball seat mounting system, the stud length beyond the brake drum should be from 1.31-1.44" as measured from the brake drum to the end of the stud. Call ConMet at 1-800-547-9473 for the correct stud part number for your application.



Measuring Stud Standout
FIGURE 91


- 2. In environments where a corrosion inhibitor is beneficial, ConMet recommends the use of Corrosion Block, a product of Lear Chemical Research, (905) 564-0018. In severely corrosive environments, a light coat of Corrosion Block on the drum and wheel pilots has proven beneficial.
- 3. In addition to the above preparation, apply two drops of oil to a point between the nuts and nut flange washer and two drops to the last two or three threads at the end of each stud. Also, lightly lubricate the pilots on the hub to ease wheel installation and removal.

8. BRAKE AND WHEEL INSTALLATION (CONTINUED)




Do not get lubricant on the mounting face of the drum or wheel. Failure to clean lubricant from these surfaces may result in decreased clamping load.

- 4. Before installation of brake drums and wheels that utilize the hub piloted system, rotate the hub so one of the wheel pilot bosses is at the top (12 o'clock position) (see figure 92).



Rotating the Hub
FIGURE 92

- 5. Position the brake drum over the hub, so it seats on the drum pilot and against the hub face.
- 6. Place the wheel(s) into position. One or more nuts can be started in order to hold wheel(s) and drum into position.
- 7. Snug the top nut first. Apply 50 ft-lbs torque to draw the brake drum up fully against the hub (see figure 93).



Reinstalling the Wheel
FIGURE 93

- 8. Install the remaining wheel nuts and using the sequence as shown, torque all the nuts to 50 ft-lbs, then retorque to 450-500 ft-lbs (see figure 89

and figure 90). The last nut rotation must be with a calibrated torquing device.

NOTE

When torquing wheel nuts, the temperature of all the wheel end components should be as close as possible to the midpoint of the expected operating range. For example, if the hub will operate between 0°F and 150°F, 75°F is a good temperature to torque at. Room temperature is often a close approximation of the midpoint temperature.

This recommendation is due to the differences in the coefficient of thermal expansion for the various materials in the wheel end including the hub, studs, wheel and brake drum. If the wheel nuts are torqued at temperatures well below the midpoint, when the system warms up, the studs may become overstressed. This could cause the studs to be permanently stretched, leading to nut loosening or damage to the wheel or hub. If the torque is applied at elevated temperatures, the system may become loose and lose clamp at lower temperatures, resulting in wheel damage and broken wheel studs. If the nuts must be torqued at extreme temperatures, the nut torque should be readjusted when the temperature is in the desired range. See also TMC RP250 "Effects of Extreme Temperatures on Wheel Torque and Clamp Load".

NOTE

Use the appropriate nuts with the above technique to install the front and outer dual wheels. Follow your shop practice to locate the valve stems.

- 9. Inspect the brake and wheel installation by checking the seating of the wheel(s) and drum at the pilots, and by turning the wheel(s) and checking for any irregularity.



Excessive or inadequate wheel nut torque can cause a failure of the wheel mounting system and a wheel separation resulting in severe personal injury or death and property damage. Always use a device that measures the torque being applied. After the first 50-100 miles, retorque all the nuts to 450-500 ft-lbs. Loosen the outer nuts to retorque the inner nuts.

Ball Seat Wheel Mounting System

- 1. Clean all mating surfaces on the hub, drum, wheels and nuts. Remove loose paint, scale, and any material building around the pilots of the drum, hub, and wheels. Be sure paint is fully cured on recently refurbished wheels.


NOTE

When dual wheels are mounted, the stud length beyond the brake drum (standout) should be from 1.31-1.44" as measured from the brake drum to the end of the stud (see figure 94).

When mounting dual aluminum wheels, use ALCOA inner cap nuts 5978R and 5978L or the equivalent. These nuts can also be used with longer studs up to 1.88" standout.

For special single aluminum wheel applications on drive and trailer hubs, use ALCOA single cap nuts 5995R and 5995L, or 5554R and 5554L or the equivalent, depending on the stud thread length (see Table A).

For single steel wheel applications, use BATCO 13-3013R and 13-3013L or the equivalent (see Table B).



Stud Standout
FIGURE 94

8. BRAKE AND WHEEL INSTALLATION (CONTINUED)

Table A: Single Aluminum Wheel Applications

Aluminum Wheels	ALCOA Cap Nut Number
3/4-16" Threaded Studs	5995R and 5995L or 5554R and 5554L, depending on stud length

Table B: Single Steel Wheel Applications


Steel Wheels	BATCO Cap Nut Number
3/4-16" Threaded Studs	13-3013R and 13-3013L

- 2. When installing the inner wheel and tire assembly, verify the inner nuts being used are suitable for the application: aluminum wheels, steel wheels, brake drum thickness, etc.




Inner cap nuts must be deep enough to ensure the stud will not bottom inside the nut and must be of a configuration approved by wheel manufacturer.

- 3. Rotate the hub to bring a drum pilot to the top (12 o'clock) position (see figure 95). Position the inner wheel and tire assembly over the studs against the drum.




Rotating the Drum Pilot to 12 O'Clock
FIGURE 95

- 4. Beginning in the 12 o'clock position, install the inner cap nuts by hand to ensure they are not cross-threaded. Do not tighten any nuts at this time.
- 5. Apply sufficient torque (about 50 ft-lbs) to the inner top cap nut to draw the brake drum up on the drum pilot and against the hub and seat the ball seat of the nut into the ball socket of the wheel (see figure 96).




Tightening the Inner Cap Nuts
FIGURE 96

- 6. To properly center the wheel, snug the remaining wheel nuts. Verify the drum is in place over the drum pilots (see figure 97).



10 Stud Tightening Sequence
FIGURE 97

- 7. Starting with the top nut first and using a staggered pattern, torque the inner wheel nuts in stages to 450-500 ft-lbs (see figure 98). The last nut rotation must be with a calibrated torquing device.




Torquing the Inner Wheel Nuts
FIGURE 98

NOTE

Use the appropriate nuts with the above technique to install the front and outer dual wheels. Follow your shop practice to locate the valve stems.

- 8. Install the outer wheel and nuts and tighten to 450-500 ft-lbs (see figure 99). The last nut rotation must be with a calibrated torque device.



Torquing the Outer Wheel Nuts
FIGURE 99

- 9. Inspect the brake and wheel installation by checking the seating of the wheel(s) and drum at the pilots and by turning the wheel(s) and check for any irregularity.



Excessive or inadequate wheel nut torque can cause a failure of the wheel mounting system and a wheel separation resulting in severe personal injury or death and property damage. Always use a device that measures the torque being applied. After the first 50-100 miles, retorque all the nuts to 450-500 ft-lbs. Loosen the outer nuts to retorque the inner nuts.

9. WHEEL HUB AND ROTOR


WHEEL HUBS WITH ConMet DISC BRAKE ROTORS

- This section applies to brake rotors designed and manufactured by ConMet for air disc brake applications. ConMet also manufactures hub assemblies equipped with brake rotors designed and manufactured by other brake companies. If your vehicle is equipped with a brake rotor other than a ConMet design, please refer to the vehicle or component manufacturer's published service information.
- Information relating to disc brake calipers, pads, or other vehicle-related systems is not included in this manual. Information regarding other brake-related components should be obtained from the vehicle or component manufacturer's published service information.

Part Number Identification

Before you perform any service procedures, you must first determine if the vehicle is equipped with a disc brake rotor designed and manufactured by ConMet.

ConMet rotors can be identified by part number. The part numbers are cast into the rotor as shown in figure 100 or stamped into the rotor as shown in figure 101.




Cast Rotor Part Number
FIGURE 100




Stamped Rotor Part Number
FIGURE 101

Use this part number to find the part specific service information in section 12 of this manual.


Rotor Identification




Flat Rotor
FIGURE 102



U-Shaped Rotor
FIGURE 103



Hat Rotor
FIGURE 104



Splined Rotor
*Bendix Splined Rotor – Refer to Bendix for splined rotor information
FIGURE 105

10. HUB AND ROTOR INSPECTION

HAZARD ALERT MESSAGES

Read and observe all hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.

WARNING

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

Do not work under a vehicle supported only by jacks. Jacks can slip and fall over. Serious personal injury and damage to components can result.

Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving. Support the vehicle with safety stands.

WARNING

Some brake linings contain asbestos fibers, a cancer and lung disease hazard. Some brake linings contain non-asbestos fibers, whose long-term effects to health are unknown. Use caution when handling both asbestos and non-asbestos materials.

DISC BRAKE ROTOR INSPECTION

A disc brake component inspection should be a part of any pre-trip inspection and regularly-scheduled preventive maintenance program.

WARNING

Follow all shop safety procedures before beginning vehicle inspection.

1. Lift and support the axles with safety stands. Refer to the vehicle manufacturer's recommended instructions.


2. Remove the wheels from the hub.
3. Rotate the hub and visually inspect both sides of the rotor for the out of service conditions detailed in this section. If any of these conditions are found, remove the hub and replace the rotor according to the instructions in this manual.

Heat Checks

Heat checks are caused by the repeated heating and cooling of the braking surface. They appear as short, thin, radial interruptions in the braking surface. There may be numerous light and heavy heat checks on the braking surface. See figure 106 for examples of light heat checking and figure 107 for heavy heat checking.


Cracks

Heat checks may wear away or they may eventually become braking surface cracks. Rotors should be replaced if cracks become over 0.060" wide or over 0.060" deep and extend over 75% of the braking surface in the radial direction.




Heavy Heat Check
FIGURE 107

Cracked rotors may be caused by mishandling, brake balance issues, wear beyond the minimum allowable thickness, or driver abuse. If a crack extends through a section of the rotor, the rotor should be replaced. If a crack is found on the mounting section of the rotor, the rotor should be replaced. Figure 108 shows a cracked rotor that should be replaced. The crack in figure 109 is acceptable to run, but the rotor should be inspected on a regular basis to ensure that the crack has not progressed.




Unacceptable Crack
FIGURE 108



Light Heat Check
FIGURE 106


10. HUB AND ROTOR INSPECTION (CONTINUED)



Acceptable Crack
FIGURE 109

Deep Grooves or Scoring

Grooves or scoring may be caused by contaminants trapped between the lining and the rotors, worn out linings, or the lining plate contacting the rotor. Grooves or scoring on the brake rotor are acceptable if they are less than 0.060" deep. If the rotor thickness, when measured across a groove, is less than the minimum allowable thickness for the rotor, the rotor should be replaced. See figure 110 for example of grooves on the braking surface of the rotor.




Grooves on Brake Surface
FIGURE 110

Blue Marks or Bands

If the rotor has become extremely hot, the braking surface may exhibit blue marks or bands. See figure 111 for examples of these marks. This condition may be caused by continued hard stops, improper brake balance, improper brake caliper clearance, operation, or


adjustment. The cause of overheating should be determined and corrected. It is not necessary to replace the rotor as long as it meets the proper dimensional specifications for runout and thickness.



Blue Marks
FIGURE 111

Polished Rotors

A polished rotor will have a mirror-like finish on the braking surface (see figure 112). This condition may be caused by improper lining friction rating, lightly dragging brakes, or a rotor resurfaced to too fine of a microfinish. To correct this condition, sand the braking surface on the rotor and the brake pads with 80 grit emery cloth. The microfinish should be 120 to 150 RMS. If the condition returns, verify that the linings on the brake pads have the correct friction rating for the application.




Polished Rotor
FIGURE 112

Martensite Spotted Rotors

Rotors subjected to extremely high heat followed by rapid cooling can exhibit a Martensite Spotted condition. This condition appears as black spots on the rotor that are slightly raised and are hard and brittle (see figure 113). The high temperatures cause a structural change to the rotor material. This condition can make the rotor more susceptible to cracking.

Rotors with this condition should be replaced. Check the brake linings for uneven wear and replace as necessary. After the rotor has been replaced, and the hub and rotor reinstalled onto the axle, the brake system should be checked for brake drag and proper brake balance.



Martensite Spotted Rotor
FIGURE 113

Grease-Stained Rotors

Brake rotors that have discolorations due to grease or oil on the brake surface should be removed from the vehicle and cleaned to remove the grease or oil (see figure 114). The brake pads should be inspected and replaced if they are found to be soaked with grease or oil. The source of the grease or oil should be identified and repaired.




Grease-Stained Rotor
FIGURE 114

Lining Transfer

High operating temperatures or improper lining material can result in brake lining transfer onto the braking surface of the brake rotor (see figure 115). This may start as a spotty thin layer of lining material that has become welded to the brake rotor and may end up covering most of the braking surface. This condition will accelerate lining wear.

The buildup can be removed by resurfacing the brake rotor. Rotors should not be resurfaced to less than 0.060" above the minimum allowable thickness to allow for wear. The cause of the high brake operating temperature should be identified and corrected before the vehicle is put back into service.



Lining Transfer
FIGURE 115

10. HUB AND ROTOR INSPECTION (CONTINUED)

Clogged or Restricted Vent Holes

Off-road and severe-duty applications may result in vent holes in the rotor becoming blocked by an accumulation of debris such as rocks or dirt (see figure 116). The vent holes should be cleaned as required to allow air flow and proper cooling of the brake rotor.




Clogged Vent Holes
FIGURE 116

Rotor Runout


Lateral runout, or wobble, on the rotor braking surface should not exceed 0.020" in one full revolution of the rotor. The measurement should be taken with a dial indicator at the center of the rotor braking surface. See figure 117 for proper runout measurement set up.

The runout measurement should not include end play of the wheel bearings. If the runout measurement is over 0.020", the end play of the wheel bearings should be checked. If the wheel bearing end play is greater than the manufacturer's recommendations, the wheel bearings should be adjusted per the manufacturer's recommendations.

Radial runout on the outside diameter of the braking surface should not exceed 0.035" when checked with a dial indicator (see figure 118). If the runout exceeds 0.035", the rotor should be replaced.




Lateral Runout
FIGURE 117



Radial Runout
FIGURE 118


Rotor Thickness

The rotor thickness should be measured at three points using a micrometer as shown in figures 119, 120 and 121. If the rotor thickness varies more than 0.005" between any two places, the rotor should be replaced.




Top of Rotor
FIGURE 119

10. HUB AND ROTOR INSPECTION (CONTINUED)



Middle of Rotor
FIGURE 120



Bottom of Rotor
FIGURE 121

Rotor Resurfacing

ConMet does not recommend resurfacing disc brake rotors. However, if rotor resurfacing is necessary, be sure that at least 0.060" of material is left above the rotor minimum thickness specification to allow for wear before the minimum allowable rotor thickness is reached.

11. HUB AND ROTOR REMOVAL AND DISC REPLACEMENT

HAZARD ALERT
MESSAGES

Read and observe all hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.



Do not work under a vehicle supported only by jacks. Jacks can slip and fall over. Serious personal injury and damage to components can result.

Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving.

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

HUB AND ROTOR
REMOVAL

1. Lift the axle and support it with safety stands. Refer to the vehicle manufacturer's recommended instructions.
2. Remove the tires and wheels.
3. Remove the hubcap or drive axle. Refer to the manufacturer's recommended instructions.
4. Follow the brake manufacturer's instructions to remove the brake caliper and brake pads from the axle mounting point.



Do not loosen the axle spindle nuts by either striking them directly with a hammer, or striking a drift or chisel placed against them. Damage to the parts will occur causing possible loss of axle wheel-end components and serious personal injury.

5. Remove the spindle nut assembly.

NOTE

Refer to Conventional, PreSet and PreSet Plus hub removal procedures in this manual for specific spindle nut removal instructions.

6. Slide the hub and rotor assembly off the spindle. Be careful not to damage the outer bearing.
7. Remove the bolts that secure the rotor to the hub. Be careful not to damage the ABS tone ring when the rotor is removed.
8. Remove the seal from the hub.
9. Clean the bearing cups and cones, bearing spacer, grease cavity, and seal bore of the hub.
10. Inspect all components for signs of wear or damage. Replace components as necessary.
11. Clean the spindle. It may be necessary to remove the inner portion of the seal from the spindle. If necessary, use emery cloth to remove rust and foreign material from the seal journal on the spindle.
12. Clean the rotor mounting area of the hub.

DISC BRAKE ROTOR
REPLACEMENT



Do not hit steel parts with a steel hammer. Pieces of a part can break off. Serious personal injury and damage to components can result. Use a brass or synthetic mallet for assembly and disassembly procedures.

PART IDENTIFICATION

The brake rotor can be identified by the part number that is cast or stamped into the rotor. Use the brake rotor part number to find the specific replacement instructions for the hub and rotor assembly you are working on (see figures 122 and 123).



Cast Part Number
FIGURE 122



Stamped Part Number
FIGURE 123



Service Kit Part Number 10020611
ConMet Flat Rotor 10019996
Rotor Minimum Thickness 1.42" (36.1mm)




ConMet 10019996 MD Flat Rotor

DISC BRAKE ROTOR REPLACEMENT

NOTE

Install the brake rotor using only the hardware provided in the kit.

1. Clean the rotor mounting surfaces and position the rotor onto the hub.
2. Using the new fasteners included in the kit, thread in all 10 cap screws with a washer on each. Torque in a star pattern to 110 ft.-lbs.



12. DISC BRAKE ROTOR REPLACEMENT (CONTINUED)

ConMet Flat Rotor 10016195
Service Kit Part Number 10018609
Rotor Minimum Thickness 1.46" (37 mm)

NOTE


Install the brake rotor using only the hardware provided in the rotor kit.

1. If the studs were removed, apply Loctite® 272 to the coarse threaded end of the double-ended stud and to the rotor mounting threads in the hub. Install the studs. Clean all mating surfaces.


NOTE

If Loctite® 272 is not available, use Loctite® 262.

2. Clean all mating surfaces.
3. Place the steel insulator and rotor on the hub.
4. Install and torque the rotor mounting bolts in a star pattern to 190-210 ft.-lbs.
5. Place the ABS tone ring on the rotor.
6. Install and torque the #8-32 UNF truss head screws in a star pattern to 18-22 in.-lbs.




ConMet Flat Rotor
FIGURE 126



Rotor Installation
FIGURE 127

12. DISC BRAKE ROTOR REPLACEMENT (CONTINUED)

ConMet Flat Rotor 10009970
Service Kit Part Number 10012091 (FF Steer)
Rotor Minimum Thickness 1.46" (37 mm)



ConMet Flat Rotor
FIGURE 128

NOTE

If Loctite® 272 is not available, use Loctite® 262.


1. If the rotor mounting studs were removed from the hub during disassembly, apply Loctite® 272 to the coarse end of the double-ended stud and to the rotor mounting threads in the hub. Install the studs.
2. Clean all mating surfaces.
3. Place the steel insulator and the rotor on the hub.
4. Install and torque the rotor mounting nuts in a star pattern to 190-210 ft-lbs.
5. Place the ABS ring on the rotor.
6. Install and torque the #8-32 UNF truss head screws in a star pattern to 18-22 in-lbs.

NOTE

Install the brake rotor using only the hardware provided in the brake rotor kit.

1. Flat Rotor
2. Hub Assembly
3. #8-32 UNF Truss Head Screw
4. ABS Tone Ring
5. 5/8"-18 UNF Flanged Hex Head Nut (10 ea.)
6. Stainless Steel Insulator

See ConMet Service Manual for detailed hub service information.



Rotor Installation
FIGURE 129



Service Kit Part Number 10084199
ConMet Flat Rotor 10083615
Rotor Minimum Thickness 1.46" (37mm)



ConMet 10083615 Flat Rotor

DISC BRAKE ROTOR REPLACEMENT


NOTE

Install the brake rotor using only the hardware provided in the kit.
If present, retain stainless steel insulator (see image below).

1. If the rotor mounting studs were removed from the hub during disassembly, apply Loctite® 272 to the coarse end of the double-ended stud and to the rotor mounting threads in the hub. (If Loctite® 272 is not available, use Loctite® 262.) Install and torque the rotor studs to 65 ft-lbs. for iron hubs and 50 ft-lbs. for aluminum hubs.
2. Clean all mating surfaces.
3. Place the stainless steel insulator (for aluminum hubs only) and the rotor on the hub.
4. Install and torque the new, included rotor mounting nuts in a star pattern to 200 ft-lbs.
5. Place the ABS tone ring on the rotor.
6. Install and torque the new, included 1/4-20 UNF button head screws in a star pattern to 160 in-lbs.

1. Hub Assembly (not included)
2. Stainless Steel Insulator (not included, for aluminum hubs only)
3. 10083615 Flat Rotor
4. 5/8"-18 UNF Flanged Hex Head Nut (10 ea.)
5. ABS Tone Ring
6. 1/4-20 UNF button head screws (5 ea.)

See ConMet Service Manual for detailed hub service information.



DO NOT THROW AWAY STAINLESS STEEL INSULATOR



Service Kit Part Number 10083923
ConMet FF-Front Flat Rotor 10083733
Rotor Minimum Thickness 1.46" (37mm)




ConMet 10083733 Flat Rotor

DISC BRAKE ROTOR REPLACEMENT

NOTE

Install the brake rotor using only the hardware provided in the kit.
If present, retain stainless steel insulator (see image below).

1. If the rotor mounting studs were removed from the hub during disassembly, apply Loctite® 272 to the coarse end of the double-ended stud and to the rotor mounting threads in the hub. (If Loctite® 272 is not available, use Loctite® 262.) Install and torque the rotor studs to 65 ft-lbs. for iron hubs and 50 ft-lbs. for aluminum hubs.
2. Clean all mating surfaces.
3. Place the stainless steel insulator (for aluminum hubs only) and the rotor on the hub.
4. Install and torque the new, included rotor mounting nuts in a star pattern to 200 ft-lbs.
5. Press the ABS ring onto the hub.



Service Kit Part Number 10083924
ConMet R-Drive Flat Rotor 10083733
Rotor Minimum Thickness 1.46" (37mm)




ConMet 10083733 Flat Rotor

DISC BRAKE ROTOR REPLACEMENT

NOTE

Install the brake rotor using only the hardware provided in the kit.
If present, retain stainless steel insulator (see image below).

1. If the rotor mounting studs were removed from the hub during disassembly, apply Loctite® 272 to the coarse end of the double-ended stud and to the rotor mounting threads in the hub. (If Loctite® 272 is not available, use Loctite® 262.) Install and torque the rotor studs to 65 ft-lbs. for iron hubs and 50 ft-lbs. for aluminum hubs.
2. Clean all mating surfaces.
3. Place the stainless steel insulator (for aluminum hubs only) and the rotor on the hub.
4. Install and torque the new rotor mounting nuts, included with the service kit, in a star pattern to 200 ft-lbs.
5. Place the ABS tone ring on the rotor.
6. Secure the ABS tone ring on the rotor using the snap retaining ring. Ensure the snap retaining ring is fully seated in the grooves of the rotor tabs.





Service Kit Part Number 10085621
ConMet Flat Rotor 10084701
Rotor Minimum Thickness 1.46" (37mm)




ConMet 10084701 Flat Rotor

DISC BRAKE ROTOR REPLACEMENT

NOTE

Install the brake rotor using only the hardware provided in the kit.
If present, retain stainless steel insulator (see image below).

1. If the rotor mounting studs were removed from the hub during disassembly, apply Loctite® 272 to the coarse end of the double-ended stud and to the rotor mounting threads in the hub. (If Loctite® 272 is not available, use Loctite® 262.) Install and torque the rotor studs to 65 ft-lbs. for iron hubs and 50 ft-lbs. for aluminum hubs.
2. Clean all mating surfaces.
3. Place the stainless steel insulator (for aluminum hubs only) and the rotor on the hub.
4. Install and torque the new rotor mounting nuts, included with the service kit, in a star pattern to 200 ft-lbs.
5. Place the ABS tone ring on the rotor.
6. Secure the ABS tone ring on the rotor using the snap retaining ring. Ensure the snap retaining ring is fully seated in the grooves of the rotor tabs.



Part No. 10085835 -
7-2019 Printed in the USA

Consolidated Metco, Inc.
5701 SE Columbia Way, Vancouver, WA 98661 (800) 547-9473 • www.conmet.com



Service Kit Part Number 10041216
ConMet FF-Front Flat Rotor 10034621
Rotor Minimum Thickness 1.46" (37 mm)




ConMet 10034621 Flat Rotor

DISC BRAKE ROTOR REPLACEMENT

NOTE

Install the brake rotor using only the hardware provided in the kit.
If present, retain stainless steel insulator (see image below).

1. If the rotor mounting studs were removed from the hub during disassembly, apply Loctite® 272 to the coarse end of the double-ended stud and to the rotor mounting threads in the hub. (If Loctite® 272 is not available, use Loctite® 262.) Install and torque the rotor studs to 65 ft-lbs. for iron hubs and 50 ft-lbs. for aluminum hubs.
2. Clean all mating surfaces.
3. Place the stainless steel insulator (for aluminum hubs only) and the rotor on the hub.
4. Install and torque the new, included rotor mounting nuts in a star pattern to 200 ft-lbs.
5. Press the ABS ring onto the hub.



Part No. 10085398 -
7-2019 Printed in the USA

Consolidated Metco, Inc.
5701 SE Columbia Way, Vancouver, WA 98661 (800) 547-9473 • www.conmet.com



Service Kit Part Number 10041218
ConMet R-Drive Flat Rotor 10034621
Rotor Minimum Thickness 1.46" (37 mm)



ConMet 10034621 Flat Rotor

DISC BRAKE ROTOR REPLACEMENT

NOTE


Install the brake rotor using only the hardware provided in the kit.

If present, retain stainless steel insulator (see image below).

1. If the rotor mounting studs were removed from the hub during disassembly, apply Loctite® 272 to the coarse end of the double-ended stud and to the rotor mounting threads in the hub. (If Loctite® 272 is not available, use Loctite® 262.) Install and torque the rotor studs to 65 ft-lbs. for iron hubs and 50 ft-lbs. for aluminum hubs.
2. Clean all mating surfaces.
3. Place the stainless steel insulator (for aluminum hubs only) and the rotor on the hub.
4. Install and torque the new, included rotor mounting nuts in a star pattern to 200 ft-lbs.
5. Place the ABS tone ring on the rotor.
6. Install and torque the new, included 1/4-20 UNF button head screws in a star pattern to 160 in-lbs.

1. Hub Assembly (not included)
2. Stainless Steel Insulator (not included, for aluminum hubs only)
3. 10034621 Flat Rotor
4. 5/8"-18 UNF Flanged Hex Head Nut (10 ea.)
5. ABS Tone Ring
6. 1/4-20 UNF Torx Button Head Screws (5 ea.)

See ConMet Service Manual for detailed hub service information.



DO NOT THROW AWAY STAINLESS STEEL INSULATOR



Service Kit Part Number 10041215
ConMet FF-Front Flat Rotor 10037760
Rotor Minimum Thickness 1.46" (37mm)



ConMet 10037760 Flat Rotor

DISC BRAKE ROTOR REPLACEMENT

NOTE


Install the brake rotor using only the hardware provided in the kit.

If present, retain stainless steel insulator (see image below).

1. If the rotor mounting studs were removed from the hub during disassembly, apply Loctite® 272 to the coarse end of the double-ended stud and to the rotor mounting threads in the hub. (If Loctite® 272 is not available, use Loctite® 262.) Install and torque the rotor studs to 65 ft-lbs. for iron hubs and 50 ft-lbs. for aluminum hubs.
2. Clean all mating surfaces.
3. Place the stainless steel insulator (for aluminum hubs only) and the rotor on the hub.
4. Install and torque the new, included rotor mounting nuts in a star pattern to 200 ft-lbs.
5. Press the ABS ring onto the hub.

1. Hub Assembly (not included)
2. Stainless Steel Insulator (not included, for aluminum hubs only)
3. 10037760 Flat Rotor
4. 5/8"-18 UNF Flanged Hex Head Nut (10 ea.)
5. ABS Tone Ring

See ConMet Service Manual for detailed hub service information.



DO NOT THROW AWAY STAINLESS STEEL INSULATOR



Service Kit Part Number 10041217
ConMet R-Drive Flat Rotor 10037760
Rotor Minimum Thickness 1.46" (37mm)



ConMet 10037760 Flat Rotor


DISC BRAKE ROTOR REPLACEMENT

NOTE

Install the brake rotor using only the hardware provided in the kit.

If present, retain stainless steel insulator (see image below).

1. If the rotor mounting studs were removed from the hub during disassembly, apply Loctite® 272 to the coarse end of the double-ended stud and to the rotor mounting threads in the hub. (If Loctite® 272 is not available, use Loctite® 262.) Install and torque the rotor studs to 65 ft-lbs. for iron hubs and 50 ft-lbs. for aluminum hubs.
2. Clean all mating surfaces.
3. Place the stainless steel insulator (for aluminum hubs only) and the rotor on the hub.
4. Install and torque the new, included rotor mounting nuts in a star pattern to 200 ft-lbs.
5. Place the ABS tone ring on the rotor.
6. Install and torque the new, included 1/4-20 UNF button head screws in a star pattern to 160 in-lbs.



Part No. 10085399 -
7-2019 Printed in the USA

Consolidated Metco, Inc.
5701 SE Columbia Way, Vancouver, WA 98661 (800) 547-9473 • www.conmet.com



Service Kit Part Number 10030921
ConMet Hat-Shaped Rotor 10003830
Rotor Minimum Thickness 1.32" (33.5 mm)




ConMet 10003830 Hat-Shaped Rotor

DISC BRAKE ROTOR REPLACEMENT

NOTE

Install the brake rotor using only the hardware provided in the kit.

1. Clean the rotor mounting surfaces and position the rotor onto the hub.
2. Using the new fasteners included in the kit, thread in all 10 cap screws with a washer on each. Torque in a star pattern to 140 ft-lbs.



Part No. 10085396 -
7-2019 Printed in the USA

Consolidated Metco, Inc.
5701 SE Columbia Way, Vancouver, WA 98661 (800) 547-9473 • www.conmet.com



Service Kit Part Number 10082074
ConMet U-Shaped Rotor 10041006
Rotor Minimum Thickness 1.46" (37.0 mm)



ConMet 10041006 U-Shaped Rotor

DISC BRAKE ROTOR REPLACEMENT


NOTE

Install the brake rotor using only the hardware provided in the kit.

1. Clean the rotor mounting surfaces and position the rotor onto the hub.
2. Using the new fasteners included in the kit, thread in all 10 cap screws with a washer on each. Torque in a star pattern to 200 ft-lbs.

1. Hub Assembly (not included)
2. 10041006 U-Shaped Rotor
3. 5/8" Flat Washers (10 ea.)
4. 5/8"-11 UNF x 1.75" Hex Head Cap Screws (10 ea.)

See ConMet Service Manual for detailed hub service information.



Service Kit Part Number 10020682
ConMet U-Shaped Rotor 10020109
Rotor Minimum Thickness 1.46" (37mm)



ConMet 10020109 U-Shaped Rotor

DISC BRAKE ROTOR REPLACEMENT


NOTE

Install the brake rotor using only the hardware provided in the kit.

1. Clean the rotor mounting surfaces and position the rotor onto the hub.
2. Using the new fasteners included in the kit, thread all 10 cap screws with a washer on each into the rotor. Torque in a star pattern to 200 ft-lbs.

1. Hub Assembly (not included)
2. 10020109 U-Shaped Rotor
3. M16X1.5 MM Hex Head Cap Screws
4. Flat Washers (10 Ea.)

See ConMet Service Manual for detailed hub service information.





Service Kit Part Number 10082181
ConMet U-Shaped Rotor 10080753
Rotor Minimum Thickness 1.46" (37.0 mm)




ConMet 10080753 U-Shaped Rotor

DISC BRAKE ROTOR REPLACEMENT

NOTE

Install the brake rotor using only the hardware provided in the kit.

1. Clean the rotor mounting surfaces and position the rotor onto the hub.
2. Using the new fasteners included in the kit, thread in all 10 cap screws with a washer on each. Torque in a star pattern to 220 ft-lbs.



Part No. 10085402-
7-2019 Printed in the USA

Consolidated Metco, Inc.
5701 SE Columbia Way, Vancouver, WA 98661 (800) 547-9473 • www.conmet.com



Service Kit Part Number 10086065
ConMet U-Shaped Rotor 10082120
Rotor Minimum Thickness 1.46" (37.0 mm)




ConMet 10082120 U-Shaped Rotor

DISC BRAKE ROTOR REPLACEMENT

NOTE

Install the brake rotor using only the hardware provided in the kit.

1. Clean the rotor mounting surfaces and position the rotor onto the hub.
2. Using the new fasteners included in the kit, thread in all 10 cap screws with a washer on each. Torque in a star pattern to 220 ft-lbs.



Part No. 10086064-
7-2019 Printed in the USA

Consolidated Metco, Inc.
5701 SE Columbia Way, Vancouver, WA 98661 (800) 547-9473 • www.conmet.com

WHEEL HUB AND ROTOR – SERVICE PARTS LIST

Brake Rotor Minimum Thickness

Rotor Part Number	Minimum Thickness	Service Kit Part Number
10019996 Medium Duty Flat Rotor	1.42" (36.1 mm)	10020611
10016195 Flat Rotor	1.46" (37.0 mm)	10018609
10009970 Flat Rotor	1.46" (37.0 mm)	10012091 (FF Steer)
10034621 Flat Rotor	1.46" (37.0 mm)	10041216 (FF Steer) 10041218 (R-Drive)
10037760 Flat Rotor	1.46" (37.0 mm)	10041215 (FF Steer) 10041217 (R-Drive)
10003830 Hat Shaped Rotor	1.32" (33.5 mm)	10030921
10020109 U-Shaped Rotor	1.46" (37.0 mm)	10020682
10041006 U-Shaped Rotor	1.46" (37.0 mm)	10082074
10080753 U-Shaped Rotor	1.46" (37.0 mm)	10082181

NOTE: All parts must be ordered as a kit.

WHEEL TORQUE SPECIFICATIONS

Wheel End Torque Specifications

Item	Measurement	Torque (ft-lbs)	Notes
Ball Seat Wheel Nut	3/4 - 16 1-1/8 - 16	450-500	Always tighten the top nut first or pilot damage may result. If lubricant is used, apply sparingly on threads only. Do not lubricate the faces of the hub, drum, wheel or on the ball seats of the wheel nuts. The last nut rotation should be with a calibrated torque device.
Hub Pilot Wheel Nut	22 mm x 1.5 mm	450-500	Always tighten the top nut first or pilot damage may result. Apply two drops of oil between the nut and nut flange, and two or three drops to the outermost 2 or 3 threads of the wheel studs. Lightly lubricate the wheel pilots on the hub. The last nut rotation should be with a calibrated torque device.
Drive, Studs, Installation Torque	3/4 - 16 5/8 - 18 9/16 - 18 1/2 - 20	70-90 40-90 40-60 40-60	
Hub Cap	5/16 - 18	12-18	Minimum SAE Grade 5 fasteners, flat washers only.
Oil Fill Plug	1/4 NPT 3/8 NPT 9/16 - 18	20-25	O-Ring Style
Bolt-On ABS Ring Screw	8-32 1/4-20	18-22 in-lbs 155-165 in-lbs	-
Disc Brake Rotor Screw	M8 x 1.25 M16 x 1.5 1/2 - 20 9/16 - 12 5/8 - 11 5/8 - 18	18-22 190-210 100-120 130-150 190-210 210-230	-
Disc Brake Rotor Nut (Stud in Hub)	5/8 - 18	190-210	-
Drive Axle Flange Nuts			See axle manufacturer's recommendations for proper drive axle nut torque.
2-Piece Nut on PreSet (FF, FL, R, TN, TP, L)		300 Inner 200 Outer	300 minimum. Advance to nearest lock. Set wrench at 200 for outer nut. NO BACK OFF.
2-Piece Nut on PreSet (FC-Medium Duty Steer Hub)		150 Inner 100 Outer	150 minimum. Advance to nearest lock. Set wrench at 100 for outer nut. NO BACK OFF.
1-Piece Nut on PreSet (FF, FL, R, TN, TP, L)		300	300 minimum. Advance to nearest lock. NO BACK OFF.
1-Piece Nut on PreSet (FC-Medium Duty Steer Hub)		150	150 minimum. Advance to nearest lock. NO BACK OFF.
PreSet Plus Drive and Trailer Nut		500	Set wrench at 500. NO BACK OFF.
PreSet Plus Steer Nut		300	Set wrench at 300. NO BACK OFF.

NOTES

NOTES

NOTES

